

MAXXflo EVO

High efficiency condensing stainless steel storage water heater

CWH 150/302



Please read and understand these instructions before commencing installation and leave this manual with the customer for future reference.

Andrews. Built to perform.



Blank Page

Table of Contents

Ref	Subject	Page
1.0	General & Safety Information	
1.1	Description of heater	4
1.2	For whom is this manual intended?	4
1.3	Symbols used in this guide	5
2.0	Safety	
2.1	General safety	6
2.2	Regulations and standards	7
2.3	UKCA & CE Marking	8
3.0	Technical Data	
3.1	Technical data	9
3.2	Product Fiche	10
3.3	Performance data	11
3.4	General dimensions and connections	12
3.5	System Schematic examples	13
3.6	Wiring diagrams	18
4.0	Installation	
4.1	Locating the heater	20
4.2	Removing the door and inner cover	20
4.3	Cold water supply	22
4.4	Unvented design	23
4.5	Secondary return design (DHW circulation pump)	24
4.6	Condensate disposal	25
4.7	Flue systems and ventilation	26
4.8	Maximum flue lengths	35
4.9	Gas connections	36
4.10	Electrical & communication connections	37
5.0	Commissioning	
5.1	Filling and removal of air	39
5.2	Commissioning of heat engine	41
5.3	Conversion to LPG	47
5.4	Frost protection and Legionella	49
5.5	Final checks and user handover	51
5.6	Fault finding	52
6.0	Maintenance	
6.1	Routine Inspection intervals & requirements	53
6.2	Removing and changing components	60
6.3	Flushing / Descaling the heat exchangers	69
6.4	Component parts illustrations	70
6.5	Recommended spares requirements	78
6.6	Error codes	79

1.0 GENERAL & SAFETY INFORMATION

1.1 DESCRIPTION OF HEATER

This Andrews Water Heaters MAXXflo EVO is a gas fired, low NOx, twin heat engine, cascading, direct fired water heater, with an integrated stainless steel tank.

Fully automatic electronic controls are integrated into the heater, with a wide range of control and sensor options available. The controls also provides voltage free outputs for Enable, Burner On and fault indication. Full BMS integration is available through the use of Modbus and optional protocol devices.

Access to the controls of the heater via the Internet and/or mobile phone app, is possible through an optional web server device available from Andrews Water Heaters.

Each heat engine module consists of a stainless steel combustion chamber, premix burner, modulating fan, gas valve, ignition and flame detection electrodes, water pressure sensor and a NTC flue sensor for safety supervision.

Each heat engine module is equipped with NTC sensors for precise temperature control on flow and return manifolds. Fully premixed, radiating, modulating burner, integrated with gas valve to deliver precise gas/air mixture throughout the full modulation range.

Common combustion air intake manifold, takes air from boiler room (type B23 flue) or directly from outside via a combined flue system (C13, C33, C53 & C63).

The safety and operation functions of each heat engine are managed by micro processor controlled circuit boards, one for each heat engine. The upper controller also acts as the cascade master controller, modulating the heat engines according to the demand, based on data from the systems sensors. Control is performed using comparison parameters between the requested temperature and the global flow temperature.

CONTROL LOGIC:

When a demand is started (the sensor of the DHW tank is less than the set point of the DHW tank - Hysteresis), the heat engine is ignited quickly (in the case of the MAXXflo EVO 150 the second heat engine starts approximately 60 seconds after the first heat engine ignition). The controls calculate the charge setpoint (factory standard is the setpoint of the DHW tank) and the heat engine(s) modulate the pump(s) and burner(s) so that the charge temperature in the tank does not exceed the charge set point.

When the temperature at B3 sensor equals the set point of the DHW tank, the burner(s) are switched off during operation and the control elements remain in stand-by until the heat demand is restored.

If the temperature of the DHW tank (B3 sensor) is less than the DHW setpoint - DHW hysteresis, the demand will be restarted and the operation as described above will start again.

1.2 FOR WHOM IS THIS MANUAL INTENDED?

This manual is intended for the heating specialist who installs commercial / industrial heating plant and equipment.

1.3 SYMBOLS USED IN THIS GUIDE



DANGER!

Indicates serious danger to personal safety and life



DANGER of electric shock!

Indicates serious danger from electricity to personal safety and life



WARNING!

Very hot water can cause severe burns and in extreme cases death



CAUTION!

Indicates a potentially dangerous situation for the heater and the environment



INFORMATION

Suggestions to assist the user in implementing instructions in this guide



ADDITIONAL READING

Reference to additional information in other documents

2.0 SAFETY

2.1 GENERAL SAFETY

SMELL OF GAS

If you smell gas - follow these safety instructions:

- **Do NOT** turn off or on any electrical switches (including light switches)
- **Do NOT** smoke
- **Do NOT** use the telephone
- **DO** evacuate persons away from the source of the gas smell
- **DO** close the main gas shutoff valve
- **DO** open all the windows and doors where the gas leakage has occurred
- **DO** inform the gas authority or a competent specialist as soon as possible



DANGER

This Andrews Water Heaters product has been designed and manufactured to comply with current European standards of safety. However, following an improper use, dangers could arise concerning the safety and life of the user or of other people, or damage could be caused to the heater or other objects. This heater is designed to be used in a domestic hot water supply and storage system. Any other use of this heater will be considered improper. Andrews Water Heaters declines any responsibility for any damage or injuries caused by an improper use. In order to use the heater according to its designed scope, it is essential to carefully follow the instructions given in this guide.



DANGER

This heater is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they are given supervision or instruction concerning the use of it by a person responsible for their safety. Children under the age of 12 years should not be permitted to use the heater.



DANGER

The installation, adjustment & servicing of this heater must be carried out by a competent person and installed in accordance with current standards and regulations. Failure to correctly install or maintain this heater could cause injury to persons or damage to property. The manufacturer shall not be held liable for any such injury and / or damage.



DANGER

Do not store or use explosive or easily inflammable material (such as petrol, paint or paper) in the same room where this heater has been installed.



CAUTION

Water temperature over 50°C can cause burns and in severe cases, injury or death. Children, the elderly and the physically or mentally disabled are most at risk from scald injury. Feel water before bathing and showering. Temperature limiting devices such as mixing valves should be installed whenever possible to ensure safe temperatures at hot water outlets.



CAUTION

This heater has been designed for use with G20 (natural gas) and G31 (liquefied propane gas) and is manufactured to give an efficient, safe and long service life. To ensure continued trouble-free operation of this heater at maximum efficiency, it is essential that correct installation, commissioning, operation and service procedures are carried out strictly in accordance with the instructions given in this manual.

Only original parts and accessories from the manufacturer may be used on this heater. Using non-approved parts may compromise the safety of the heater and invalidate any warranty.

In the event of failure and/or suspected faulty functioning of the heater. Switch off the heater and contact a suitable qualified technician. Do not attempt to make any repairs yourself, unless you are suitably qualified and competent to do so.



CAUTION

If the water system is not in use for periods exceeding 14 days, there is an increased risk of corrosion on all copper parts and an increase in bacterial growth. Follow the recognised measures for Anti-legionella in section 5.4.2. to manage this risk

2.2 REGULATIONS AND STANDARDS

This heater must be installed in accordance with relevant Standard Specifications, Codes of Practice and current Building Regulations, together with any special regional requirements of the Local Authorities, Gas undertaking and Insurance Regulations for the Electrical Equipment of Buildings. The installation of this heater must be in accordance with the relevant requirements of:

- Health and safety at work act 1974
- Building regulations 2010
- Electricity at work regulations 1989
- Management of health and safety at work regulations 1998
- Manual handling regulations 1992
- Water Supply (Water Fittings) Regulations 1999 (England and Wales)
- Water Supply (Water Fittings) Byelaws 2014 (Scotland)
- Water Supply (Water Fittings) Regulations 2009 (Northern Ireland)
- BS 7671 - Requirements for electrical installations, IET wiring, regulations
- BS 6644 - Specification for the installation of Gas fired hot water boilers for rated inputs between 70kW (net) and 1.8 MW
- BS 7074-2 - Applications selection and Installation of expansion vessels and ancillary equipment for sealed water systems.
- BS 6880:1 Code of practice for low temperature hot water heating systems of output greater than 45kW.
- BS 6880:2 Code of practice for low temperature hot water heating systems of output greater than 45kW.
- BS 6880:3 Code of practice for low temperature hot water heating systems of output greater than 45kW.
- CP 342:2 Code of practice for centralised hot water supply. Buildings other than individual dwellings.
- IGE/UP/1 - Strength testing/tightness testing/direct purging of industrial and commercial gas installations
- IGE/UP/2 - Installation pipework on industrial and commercial premises
- IGE/UP/10 - Installation of flued gas appliances in industrial and commercial premises.
- IGE/UP/16 - Design for Natural Gas installations on industrial and commercial premises with respect to Dangerous Substances and Explosive Atmospheres Regulations (DSEAR)



CAUTION

These manufacturer's notes must not be taken in any way as over-riding statutory obligations.

2.3 UKCA & CE MARKING

There is one data plate located on the heater. This is mounted on the outside of the heater (left hand side)

1 _____


2 _____

3 _____

4 _____

5 _____

6 _____



**ANDREWS
WATER HEATERS**

**UK
CA**
0558-22

CATEGORY: I2H
FLUE TYPES: B23,C13,C33,C53,C63

CE
0063-22

NG ONLY ADJUSTED FOR G20 @ 20mbar

MODEL:	MAXXflo EVO CWH 150/302	7800597
HEAT INPUT (GROSS)	Q(Hs)=	151.0kW
HEAT INPUT (NET)	Q(Hi)=	136.0kW
HEAT OUTPUT	P=	148.2kW
CO ₂ MAX RATE		9.0% (± 0.2%)

This appliance may only be installed in a room which complies with the appropriate ventilation requirements. Read the technical instructions before installing this appliance.

CONDENSING APPLIANCE

MAX WORKING PRESSURE	9 bar
CAPACITY	300 Litres
POWER SUPPLY	230V ~ 50Hz, IP20, 359W
PIN CODE	0558CU2236 / 0063CT3553
COUNTRIES OF DESTINATION	UK:IE

Year: 2022	Serial No: 123456789
-------------------	-----------------------------

Manufactured by Malvern Boilers Ltd, Malvern, WR14 1BW, for:
Baxi Heating UK Ltd, Coventry Road, Warwick, UK CV34 4LL

M10120A

KEY

- 1 Type approval designation
- 2 Gas type and pressure
- 3 Model Name
- 4 Heat, gas flow & CO₂ data
- 5 Technical data
- 6 Serial number and year

The UKCA marking documents of this heater confirms compliance with the essential requirements of the following Regulations:

- Regulation (EU) 2016/426 on appliances burning gaseous fuel, as brought into UK law
- Ecodesign for Energy-Related Products and Energy Information (Amendment) (EU Exit) Regulations 2019 No. 539
- Electromagnetic Compatibility Regulations 2016 No. 1091
- Electrical Equipment (Safety) Regulation 2016 No. 1101



This manual is an integral and indispensable part of the heater and it is suggested that this manual is kept in a safe place for future reference.

3.0 TECHNICAL DATA

3.1 TECHNICAL DATA

MAXXflo EVO

Product name			CWH 150/302
Daily electricity consumption	Q_{elec}	kWh	0.221
Declared load profile			XXL
Sound power level, indoors	L_{WA}	dB	66
Daily fuel consumption	Q_{fuel}	kWh	24.619
Emissions of nitrogen oxides	NO_x	mg/kWh	36
Weekly fuel consumption with smart controls	$Q_{fuel, week, smart}$	kWh	-
Weekly electricity consumption with smart controls	$Q_{elec, week, smart}$	kWh	-
Weekly fuel consumption without smart controls	$Q_{fuel, week}$	kWh	-
Weekly electricity consumption without smart controls	$Q_{elec, week}$	kWh	-
Storage volume	V	l	300
Mixed water at 40 °C	V_{40}	l	∞
Harmonised standards applied	EN: 13203-2		
Specific precautions that shall be taken when the water heater is assembled, installed or maintained:	Before any assembly, installation or maintenance the installation and operation manual has to be read attentively and to be followed		



3.2 PRODUCT FICHE

MAXXflo EVO




Product name		CWH 150/302
Declared load profile		XXL
Water heating energy efficiency class		----
Water heating energy efficiency	$\eta_{wh} \%$	97
Annual energy consumption	<i>AEC kWh⁽¹⁾</i>	48
	<i>AFC GJ⁽²⁾</i>	19
Other load profiles for which the water heater is suitable to use and corresponding water heating efficiency and annual electricity consumption ⁽³⁾		
Thermostat temperature setting	°C	58
Sound power level L _{WA} indoors	dB	66
Ability to off-peak hours functioning ⁽³⁾		Yes
Enabled smart control settings ⁽⁴⁾		-
(1) Electricity (2) Fuel (3) If applicable (4) If smart control setting value is "1", the water heating energy efficiency and annual electricity / fuel consumption only relate to enabled smart control settings		



3.3 PERFORMANCE DATA


PERFORMANCE	Unit	150/302
Q Maximum Heat Input net (gross)	kW	135.0 (149.9)
Q Minimum Heat Input net (gross)	kW	29.0 (32.2)
Output Max (Min)	kW	147.2 (31.5)
V Maximum Gas Consumption G20 / G31	m³/h	13.7 / 5.6
Flue gas temperature max (70°C Anti-legionella)	°C	90
CO ₂ at max output G20 / G31	%	9.0 / 9.8
CO at max output	ppm	100
NOx emission GCV	mg/kWh	36.0
NOx Class	class	6
Sound level (EN15036-1 Average @ 1m)	LAeq	66
HOT WATER		
Tank capacity	litres	300
Thermal Standby losses	kWh/day	2.26
Recovery rate through 50°C	l/hr	2,572
Recovery rate through 56°C	l/hr	2,297
Approximate Heat up time $\Delta T = 50^{\circ}\text{C}$	minutes	7.2
Approximate Heat up time $\Delta T = 45^{\circ}\text{C}$	minutes	6.5
PMS Inlet / Operating pressure max (min)	bar	9.0 (0.8)
In / Out connections	BSP	1 1/2"
Water return connection	BSP	1"
ELECTRICAL		
Electrical supply voltage / Hz	V / Hz	220 - 240 / 50
Fuse rating on mains supply	A	5
Insulation protection rating	IP	20
Power consumption - standby	W	5.5
Power consumption - maximum	W	359
FLUE		
Flue connection - single	mm	130
Flue connection - concentric	mm	130/200
Flue systems permitted	type	B23, C13, C33, C53, C63
Max flue equivalent length - open (B23)	m	44
Max flue equivalent length - concentric (C13, C33)	m	24
Max flue equivalent length - twin (C53)	m	48
Flue gas volume @ minimum load	m³/h	49.8
Flue gas volume @ maximum load	m³/h	232
Flue gas mass @ maximum load	kg/h	224
Maximum internal flue pressure @ 65°C	Pa	370
Maximum condensation production	l/h	20.0
OTHER CONNECTIONS		
Gas	BSP	1"
Condensate	mm	41mm
Tank drain	mm	22mm
WEIGHTS & CLEARANCES		
Shipping weight	kg	296
Weight empty	kg	226
Weight full	kg	539
Service clearance - rear	mm	20mm
Service clearance - right	mm	25mm
Service clearance - top	mm	400mm
Service clearance - left	mm	300mm
Service clearance - front	mm	800mm

3.4 GENERAL DIMENSIONS & CONNECTIONS




3.5 SYSTEM SCHEMATIC EXAMPLES

EXAMPLE 1: SINGLE MAXXflo EVO (SCHEMATIC)




EXAMPLE 2: PARALLEL MAXXflo EVO (SCHEMATIC)



3.5 SYSTEM SCHEMATIC EXAMPLES (CONTINUED)

EXAMPLES 1 & 2: SINGLE AND PARALLEL MAXXflo EVO (SETUP)



Main related parameter settings:


Menu	Parameter	Settings
DHW	1647 Legionella function circulation pump	If the function is turned OFF, circulation pump Q4 will be switched OFF while the "Legionella" function is performed (anti-legionella action performed on tank only). If the function is turned ON, circulation pump Q4 is switched ON while the "Legionella" function is performed (anti-legionella action performed on DHW system).
	1660 Pump release	Set desired option for activation of the DHW circulation pump, normally either activated with time program 4 (DHW) or independently of DHW via time program 5
	1661 Pump cycling	When switched on, the circulation pump Q4 will cycle on and off during the activation period (on for 10 minutes then off for 20 minutes repeatedly). Where B39 sensor has been installed this function will become active only once the circulation setpoint has been achieved
	1663 Circulation setpoint	When B39 sensor is installed on the DHW distribution return pipe, the heater controller will monitor the return temperature during the activation time of the circulation pump Q4. Whenever the temperature acquired by the sensor falls below the circulation setpoint, circulation pump Q4 will be active until the setpoint has been exceeded (minimum pump run time is 10 minutes). During a legionella cycle operation the temperature at the sensor can be used to adjust the dwell time, ensuring that the entire DHW system reaches the legionella setpoint for the total dwell time length set. The dwell time counter is not started until the temperature at the sensor reaches legionella setpoint.



Refer to "Controls Operating Instruction Manual for greater detail of the Anti-legionella function setup


3.5 SYSTEM SCHEMATIC EXAMPLES (CONTINUED)

EXAMPLE 3: MAXXflo EVO & BUFFER SS300-10 (SCHEMATIC)



3.5 SYSTEM SCHEMATIC EXAMPLES (CONTINUED)

EXAMPLE 3: MAXXFLO EVO & STORAGE TANK (SCHEMATIC)




Related settings table (in addition to example 1 table)

Menu	Parameter	Settings
Configuration	6020	Set function of extension module 1 to "Multifunctional"
	6030	Set Relay Output QX21 module 1 to "dT controller 1 K21"
	6041	Set sensor input BX22, module 1 to "Special temperature sensor 1"
General functions	5570	Factory setting : Not used
	5571	Factory setting: "- 1.5°C" - When BUFFER SS300-10 tank temperature is 0.5°C below MAXXflo EVO tank temperature K21 pump will be turned off.
	5572	Factory setting: "3.0°C" - When BUFFER SS300-10 tank temperature is less than 2.0°C below MAXXflo EVO tank temperature K21 pump will be turned on.
	5573	Factory setting : "DHW sensor B3"
	5574	Factory setting : "Special temperature sensor 1"
	5575	Factory setting : 30 seconds - Represents the minimum time that K21 pump will be activated even if parameter 5571 conditions are met.


3.5 SYSTEM SCHEMATIC EXAMPLES (CONTINUED)

EXAMPLE 4: BMS CONNECTIONS




3.6 WIRING DIAGRAM (MAXXflo EVO 150 kW MODEL)

PCB1



3.6 WIRING DIAGRAM (MAXXflo EVO 150 kW MODEL)

PCB2



4.0 INSTALLATION

4.1 LOCATING THE HEATER

The location selected for installation of the heater must allow the provision of a satisfactory flue, an adequate air supply (for type B₂₃), a drain and be well illuminated. A purpose built plant room or compartment is strongly recommended.

If a purpose built plant room is not available, measures should be taken to protect the heater from damage and prevent any extraneous matter from being stored on or around the heater. See BS 6644 Clauses 4, 5 and 6 for details.

There must be easy access to the plant room and heater at all times. The heater must be located in an area where leakage from the tank, water connections or the combined temperature and pressure safety valve will not result in damage to the area adjacent to it. When such locations cannot be avoided, a suitable drain tray must be installed under the heater. The drain tray must be no deeper than 38mm and must be 100mm wider and longer than the heater. It should be piped to an adequate drain using 20mm (0.75in) diameter pipe, angled for proper drainage.


Access must be provided to the front of the heater with adequate clearance for servicing and operation (See 3.3) The floor on which the heater is installed must be flat, level and of sufficient strength to withstand the weight of it when filled with water, and should satisfy the requirements of the Local Authority & Building Regulations.

4.2 REMOVING THE DOOR AND INNER COVER

Ensure that the heater is isolated from the power supply.

Remove the single screw (A) on the left hand side of the door.


Release the two latches (B) by pulling on the back of the latch and lifting outwards.



Open the door, and detach the case earthing lead near the upper hinge (C). Lift the door upwards and off its hinges. Place the door carefully against a wall, ensuring that it cannot fall over.

Remove the four screws (D) either side of the GUI display unit at high level. Loosen the two screws (E) at low level inside the case to remove the case retaining bracket (F). Pull the inner cover forwards and remove completely.

Please note: CWH 150kW models have two removable transit brackets (G) that will need to be removed and recycled prior to removing the inner cover for the first time.



4.3 COLD WATER SUPPLY

4.3.1 CONNECTIONS

The cold water inlet and hot water outlet connection nipples are identified on the top of the heater. Connect the cold water feed and hot water outlet to these nipples with union adaptors for ease of servicing. Fit a check valve and isolator in the cold water supply before the inlet to the water heater.



CAUTION

Do not apply excessive torque to these nipples when making connections. The use of an appropriate drinking water pipe sealing compound is recommended. The use of galvanised pipework is not recommended due to issues such as galvanic attack.

4.3.2 SYSTEM

The MAXXflo EVO range of storage water heaters are designed to operate from a mains fed unvented water supply. An unvented system kit is available from Andrews Water Heaters. However, the heater may be connected to an open vent supply provided the minimum supply pressure of 0.8 bar are maintained at all times.



CAUTION

This heater is factory fitted with temperature and pressure relief valves. An unvented system must be fitted by an approved installer. Avoid water stagnation : If this new installation is not to be used immediately, it should be drained down

4.3.3 WATER QUALITY AND TREATMENT

In order to ensure the long service life of this appliance and all connected pipe work, a sample of drinking water should be analysed before installation and compared against the following table:

Hardness	< 150ppm (10.6 Clark degrees)
Acidity	6.0pH to 8.5pH

If water sample readings are outside the limits given above, corrective action should be taken. For example, the installation of a base exchange water treatment in areas of hard water.



CAUTION

When installing Andrews Water Heaters in hard water areas we would recommend that a water treatment specialist is consulted.

4.3.4 DE-STRATIFICATION PUMP

By virtue of its design, an internal DHW tank de-stratification pump is not required

4.3.5 ANTI-VACUUM VALVE

An Anti-vacuum valve must be fitted to prevent a vacuum forming in installations where there is the potential of the draw off rate exceeding the rate of flow to the inlet; this can occur in properties with multiple outlets below the base of the hot water heater. The valve contains a check cartridge which under normal conditions is held closed by the system pressure. When a vacuum condition exists, the suction will cause the check cartridge to open and air to flow through, equalising the pressure within the hot water heater. The capacity of an anti-vacuum valve should be equal to or greater than the rate of the vacuum formation in the vessel being protected. An Anti-vacuum valve kit (part number 7709364) is available for the MAXXflo EVO that is capable of up to 3 litres/sec @ 500mbar.

4.4 UNVENTED DESIGN



DANGER

Unvented systems should only be fitted by an approved installer

When using the heater on an unvented hot water storage system, the Unvented System Kit, part number 7726954, available from the manufacturer **must** be fitted. When used in an unvented system, the heater will supply hot water at a maximum of 6 bar or at the pressure available at the mains feed if this is lower. During conditions of no-flow, system pressure may rise to a maximum of 8 bar, whilst the burner is operating. When testing the system, it is recommended that a maximum test pressure of 9 bar is used.


For the hot water supply, a 24 litre expansion vessel is suitable for the stored volume of all models and an average pipework system. For systems with larger pipe volumes or additional storage, expansion vessels with greater capacity are available. Assemble the components of the unvented system kit as shown below



When assembling the Pressure Reducing Valve and Double Non-Return Valve, ensure that the flow arrows marked on the components are pointing in the direction of flow, that is towards the heater.


The relief valves fitted to this heater must not be used for any other purpose. No fitting should be installed between the expansion valve and the cylinder. The cold water for services may be drawn from the 22mm compression port up stream of the Pressure Reducing Valve. The water pressure at this point will be similar to that available at the hot water outlet of the water heater. If higher flow rates are required for the cold water services, a suitable tee fitting should be fitted to the pipework, upstream of the Pressure Reducing Valve.

All fittings and materials supplying water to the storage vessel must be suitable for use with drinking water and listed in the current Water Research Centre "Materials and Fittings Directory". Installation of unvented hot storage water systems must comply with Part G of Schedule 1 of the Building Regulations.



4.5 SECONDARY RETURN DESIGN (DHW CIRCULATION PUMP)

A Secondary Return circuit may be fitted to the 1" nipple at the top of the heater. In all cases, for serviceability, the recirculation pipe must be fitted with a stop valve immediately before the connection point.



See Section 3.6 Example 1 for wiring details

If a secondary return circuit is fitted with a secondary pump, please ensure that the flow-rate does not exceed the heater maximum flow-rate. An excessive flow in the secondary circuit could result in a temperature mixing effect in the heater storage vessel, resulting in a stored water temperature less than set temperature.

See table below:-

Model Type	MAXXflo EVO 150
Maximum flow rate m ³ /h	1.8



It is important that the heat losses from the return system are minimised (through pipe insulation), otherwise the heater may be operating for extended periods of time on minimum load, constantly replacing the heat lost from the return system pipes.

4.6 CONDENSATE DISPOSAL

Condensation is formed in the normal operation of the heater and this must be continuously discharged into a drain. Given the acidity level of condense discharge (pH 3.5 - 4.5) only plastic material can be used for the discharge pipe work. For a MAXXflo EVO 150 each 75kW heat engine can produce up to 7.5 litres of water per hour, whilst at full load.

Use of 40mm plastic pipe with a drop of at least 45 mm for every metre of pipework is recommended. The trap supplied as part of the appliance can be connected into an internal drain in many cases without the requirement for an additional air break. Wherever possible all condensate pipework should be installed inside the plant room.

Any external pipework passing through a wall to the outside should be run in a minimum of 40mm diameter. External pipework should be insulated to a minimum of 13mm protection against frost and freezing temperatures. Insulation must be waterproof and UV resistant. The end of the pipe must be cut at 45° and be insulated to the tip of the pipe.




CAUTION

The condensate trap must be filled with water before operating the heater (see 5.1.2 for suggestions on how to do this)




It is important that the condensate flow must be maintained, even in freezing conditions. In the event that the condensate becomes blocked, the heater will shutdown completely, and will not operate again until the flow has been restored.

EXTERNAL CONDENSATE DISPOSAL EXAMPLES



Soil / Vent Stack

There is no requirement for an additional trap or air break when connecting drain pipework to an internal or external soil or vent stack



Gully

There is no requirement for an additional trap if discharging direct into an open gully.

4.7 FLUE SYSTEMS AND VENTILATION

4.7.1. GENERAL REQUIREMENTS



CAUTION

The installer is responsible for ensuring that the right type of flue system is used and that the diameter and length are correct. For optimal installation, the accessories supplied by Andrews Water Heaters should ensure that the correct system components are used.

The coupling and connection methods may vary depending on the manufacturer of the flue system. It is not permitted to combine pipes, coupling and connection methods from different manufacturers. This also applies to roof feed-throughs and common channels.

If connecting this heater to an older existing flue system, care must be taken to ensure that this system is of the correct size and specification. If the flue system is aluminium, a condensate trap must be fitted in the flue before it connects to the heater.

This water heater may not be used in areas where chemical substances are stored or used. Some propellants, bleaching and cleaning agents disperse explosive vapours and / or cause accelerated corrosion. Be aware that this water heater may be vulnerable to accelerated corrosion from salty air e.g. Coastal installations

- Refer to the following standards and guidance notes before installing the flue system :


BS6644 : Specification for the installation of gas-fired hot water boilers of rated inputs between 70kW (net) and 1.8MW (net)

IGEM UP 10 : Installation of flued gas appliances in industrial and commercial premises

4.7.2 SUITABLE FLUE MATERIAL

When using a flue system that has not been supplied by Andrews Water Heaters, make sure that they are certified for the type and use. Check the text string printed on the flue system to ensure the correct materials are selected. See the example below for guidance:

Example text



1. This material is CE approved to this standard. EN 14471 for plastic flue and EN 1856-1 for metal flue
2. Temperature rating: Class cannot be lower than T120, but can be higher
3. Pressure rating: P & H ratings are allowed, N rating is not allowed
4. Condensate resistance: Must be W (wet) rated. D (dry) rating is not allowed
5. Corrosion resistance: Must be V1 (gas combustion products) rated. V2 & V3 are not allowed
6. Material: Must be L11 minimum (Aluminium) but can be higher
7. Fire resistance class: Classed A through to E are allowed. Class F is not allowed

4.7.3 GENERAL VENTILATION REQUIREMENTS (TYPE B₂₃ CLASSIFICATION)



DANGER

Flue type B₂₃ - Is an open flue appliance where air is drawn from the room or compartment in which the heater is installed and therefore the room or compartment must be ventilated to outside air. Only in exceptional circumstances can ventilation air be taken from inside (see IGEM/UP/10 section 7 for details)

Adequate ventilation shall be provided to permit the safe operation of any appliance installed within the room or space, including other fuel-fired appliances which may be affected by the installation of this gas appliance. If the installation of this appliance takes the total net kW input in the room or space beyond 70kW, reference to BS6644 should be made.

Consideration shall be given to the purpose of the internal space from which ventilation is provided. The internal space should not be part of a dwelling


The ventilation system (including mechanical ventilation) shall be designed such as not to cause the installation space to be under suction to the extent that downdraft in the chimney system could lead to a reverse flow of combustion products into the room or appliance.

When installing an appliance with a B₂₃ flue system, it is recommended that a gas alarm and a CO alarm is fitted in the same room or compartment from which the air is drawn.

The temperature within a room, enclosure or balanced compartment, assuming ambient air conditions of 15°C shall not exceed the following temperatures:

High level (100mm below ceiling level)	40°C
Mid level (1500mm from floor level)	32°C
Low level (100mm above floor level)	25°C


4.7.4 OPEN FLUE APPLIANCE IN A DEDICATED PLANT ROOM



Installations in a plant room with ventilation direct to outside air require the following minimum free area of permanently open vents at both low and high levels:

Heater Model	Minimum vent free area (Low)	Minimum vent free area (High)
MAXXflo EVO 150	675 cm ²	405 cm ²


4.7.5 OPEN FLUE APPLIANCE IN A ENCLOSURE VENTILATED DIRECT TO OUTSIDE AIR



Installations within a compartment ventilated directly to outside air must be ventilated at high and low level. The minimum free area of permanently open vents must be as follows:-

Minimum free vent area		
Heater Model	Low level	High level
MAXXflo EVO 150	1,485 cm ²	810 cm ²

4.7.6 OPEN FLUE APPLIANCE WITH MECHANICAL VENTILATION




Mechanical ventilation can be a combination of mechanical inlet and outlet and natural ventilation outlet. The fans must be controlled so as not to cause a negative pressure (relative to atmospheric conditions) in the plant room. The fans must be interlocked with the appliance. Minimum flow rate requirements are as follows:

Heater Model	Minimum flow rate with draught diverters		Minimum flow rate without draught diverters	
	Low level Inlet	High level Extract	Low level Inlet	High level Extract
MAXXflo EVO 150	475 m ³ /h	255 - 304 m ³ /h	448 m ³ /h	158 - 207 m ³ /h

4.7.7 FLUE TERMINAL POSITIONS - B₂₃ TYPE (OPEN FLUE)

Terminals should be so positioned as to avoid products of combustion entering openings into buildings or other flues or vents

TYPICAL INSTALLATION



Code	Minimum distance (mm)	MAXXflo EVO 150
A	Directly below an opening, air brick, opening window etc	2500
B	Above an opening, air brick, opening window etc	2,170
C	Horizontally to an opening, air brick, opening window etc	2,170
D	Below gutters, soil pipes or drainpipes	200
E	Below eaves	200
F	Below a balcony or car port roof	<i>Not recommended*</i>
G	Above ground, roof or balcony level	300**
H	From vertical drain or soil pipe	150
J	From an internal or external corner to a flue terminal alongside a boundary	300**
K	From a terminal facing a terminal	3,350
L	Vertically from a terminal on the same wall	2500
M	Horizontally from a terminal on the same wall	2,170
N	From a surface or a boundary line facing a terminal	3,860
P	From a opening in a carport (e.g. door, windows) into the building	<i>Not recommended*</i>
Q	Above a pitched roof	620
R	From an adjacent wall (edge of terminal) or a vertical structure on a roof	620**
S	Above a flat roof	6250
	From any other roof flue terminal	2,170

*** Risk assessment required**

**** Plume management recommended**

Figures for guidance only, for full details refer to IGEN/UP/10 edition 4

4.7.8 ROOM SEALED FLUE (C₁₃, C₃₃, C₅₃ & C₆₃) SYSTEM

There are four approved room sealed arrangements where both the air inlet and flue discharge terminate outside the building.

Flue and air ducts are supplied to a concentric design using 130/200mm flue. See section 4.7.10 for component choices. Flues should slope back to the Heater by three degrees.

Terminal positions must comply with the requirements detailed in section 4.7.13



CAUTION

Flue type C₁₃ & C₃₃ - If separate terminal outlets are used, they shall fit inside a square of 50cm

Flue type C₅₃ - Any terminal used for the separate supply of air and for the evacuation of combustion products must not be installed on opposite walls of a building

Flue type C₆₃ - Any terminal used must comply with the requirements of BS EN 1856-1

Ensure the inner flue section is sealed at all joints, otherwise incomplete combustion may result. For ease of assembly, it is recommended that a small quantity of petroleum jelly is used to lubricate each flue seal, before fitting flue sections together.

Any terminal **must** be fitted with a guard if less than 2m above ground level or if it is in a position where it may cause harm to persons as a result of touching a hot surface.

Care must be taken to avoid long horizontal runs of flue duct and continuous discharge of condensate from a horizontal flue terminal - Ensure that the flue slopes back by 3° towards the heater

4.7.9 VENTILATION REQUIREMENTS (TYPE C₁₃, C₃₃, C₅₃ & C₆₃)

Where the heater is installed in a **DEDICATED PLANT ROOM** or **COMPARTMENT** no additional ventilation should be required, provided the following ambient conditions are not exceeded:

Air humidity	93% RH @ 25 ° C
Ambient temperature (1.5m from floor level)	32 ° C

Where the room sealed heater is installed in a boiler room with an air change rate >0.5 changes per hour, no additional ventilation is required.

If the air change rate is less than 0.5 changes per hour the following minimum free vent area will be as follows:-


Model	Min free area of high & low vent
MAXXflo EVO 150	405cm ²

4.7.10 MAXXflo EVO 150 KW FLUE PARTS


Part number:	Flue Kits - Description
7620229	VERT FLUE KIT CWH EVO 90 120 150
7620230	HORIZ FLUE TERM CWH EVO 90 120 150
Part number:	Optional Flue Parts - Description
7620232	90° ELBOW C/W CLAMP 130/200
7620233	FLUE CONDENSE TRAP PP 130/200
7726992	45° ELBOW C/W CLAMP 130/200
7726994	1M FLUE CUTTABLE 130/200
7727001	FLUE CLAMP 200MM
7727003	FLUE SEAL 130MM
E211	CONDENSATE BOTTLE PP H150
E217	FLAT ROOF PLATE
E218	ANGLED ROOF PLATE
E219	WALL CLAMP
E261	CONDENSATE SYPHON CONNECTION
E630	EXTENDED TERMINAL GUARD

4.7.11 MAXXflo EVO FLUE SET UP


Horizontal flue






Alternative flue



Vertical flue







4.7.12 MAXXflo EVO 150 KW FLUE SYSTEM DIMENSIONS

ALL Ø130/200mm CONCENTRIC FLUE


VERTICAL FLUE TERMINAL
C/W CLAMP
PART No 7620229




FLUE CONDENSE TRAP
PART No 7620233




CONDENSE TRAP
PART No E211





45 ELBOW C/W CLAMP
PART No 7726992



90 ELBOW C/W CLAMP
PART No 7620232




HORIZONTAL TERMINAL C/W WALL PLATES & CLAMP
PART No 7620230



4.7.13 FLUE TERMINAL POSITIONS - C₁₃ C₃₃ C₅₃ C₆₃ TYPE (CONCENTRIC / TWIN)

Terminals should be so positioned as to avoid products of combustion entering openings into buildings or other flues or vents

TYPICAL INSTALLATION



Code	Description	Min distance (mm)
A	Directly below an opening, air brick, opening window etc	2,500
B	Above an opening, air brick, opening window etc	1,100
C	Horizontally to an opening, air brick, opening window etc	1,100
D	Below gutters, soil pipes or drainpipes	200
E	Below eaves	200
F	Below a balcony or car port roof	*not recommended
G	Above ground, roof or balcony level	300**
H	From vertical drain or soil pipe	150
J	From an internal or external corner to a flue terminal alongside a boundary	300**
K	From a terminal facing a terminal	3,350
L	Vertically from a terminal on the same wall	2,500
M	Horizontally from a terminal on the same wall	1,100
N	From a surface or a boundary line facing a terminal	3,860
P	From a opening in a carport (e.g. door, windows) into the building	*not recommended
Q	Above apex of a pitched roof	620
R	From an adjacent wall (edge of terminal) or a vertical structure on a roof	620**
S	Above a flat roof	620
	From any other roof flue terminal	1,100

*** Risk assessment required**

**** Plume management recommended**

Figures for guidance only, for full details refer to IGEN/UP/10 edition 4

4.8 MAXIMUM FLUE EQUIVALENT LENGTHS

Permitted Flue Equivalent Length (FEL) for type B ₂₃ flue	=	40 metres
Permitted Flue Equivalent Length (FEL) for type C ₁₃ , C ₃₃ flue	=	20 metres
Permitted Flue Equivalent Length (FEL) for type C ₅₃ flue	=	40 metres

The flue duct can discharge either vertically or horizontally by selection of the correct flue terminal. The flue system can be fitted with 90° and 45° bends, as well as extensions.


Each flue accessory such as bends and straight lengths restrict the flue system and have a Flue Equivalent Length (**FEL**) which must be added together to determine the total. Referring to the table below, select a suitable flue system for the particular installation requirement and then calculate the **FEL** of the system, this must not be greater than that stated above. Note: The FEL values below are typical values. Always check with the flue supplier for exact values.

FLUE PARTS 130 / 200mm	F.E.L (C13, C33 TYPE)
1.0 m Concentric Length	1.0 m
0.5 m Concentric Length	0.5 m
Concentric 90° Bend	1.2 m
Concentric 45° Bend	0.8 m
Vertical Terminal kit	1.6 m
Horizontal Terminal kit	1.0 m
Flue Condense Trap	1.5 m
Terminal Guard	N/A
Wall Clamp 200mm	

FLUE PARTS 130mm	F.E.L (B23 TYPE)
1.0 m Length	1.0 m
0.5 m Length	0.5 m
90° Bend	4.0 m
45° Bend	2.0 m
Vertical Terminal kit	2.0 m
Horizontal Terminal kit	1.5 m
Flue Condense Trap	4.0 m
Terminal Guard	N/A
Wall Clamp 130mm	

Example C₃₃: A flue system that uses six straight lengths, three 90° bends and a horizontal terminal.

6 x 1m straight lengths	6.0 m
3 x 90° bends	3.6 m
1 x Horizontal Terminal	1.0 m
Total (within 24m limit)	10.6 m



CAUTION

Vertical sections should be secured using a support clamp every 2.5 m
Horizontal sections should be secured using a support clamp every 1.5 m



When the combustion flue system required is longer than 5.0m, it is recommended that a separate system to capture excess condensation formed inside the flue is fitted.

4.9 GAS CONNECTIONS

4.9.1 GAS SUPPLY

The installation of the gas supply must conform, to the Standards and Codes of Practice listed in Section 2.3 of this manual.


This water heater is intended to be installed only on a gas supply with a governed meter.

The gas meter, regulator and supply pipework must be sized so as to provide an adequate supply to the heater in addition to any other appliances connected to the supply (*see 3.3 for gas consumption rates*).

A 1" BSP threaded isolation valve with inlet pressure measuring point is supplied with the heater, to provide a union connection at the top right hand rear of the heater. A minimum of 19mb gas pressure, must be available at the heater inlet, with this heater and other appliances connected to the same gas supply, operating at maximum load.



In order to ensure the gas isolation valve handle falls into the closed position, it may be necessary to remove the handle and replace it 180° from its original position.



4.9.2 GAS PIPE WORK

Where this heater is installed in a plant room or purpose built compartment, a manually operated valve must be fitted. The valve must be easily identified and readily accessible.

The gas supply pipework should be fitted with suitable unions so the heater can be safely removed for major service or repair.

Check for gas tightness in pipework to the heater by connecting a manometer to the inlet pressure tapping point. Gas and combustion soundness within the heater should also be checked using sense of smell and leak detection fluid. Ensure gas tightness before moving onto commissioning.

4.10 ELECTRICAL & COMMUNICATION CONNECTIONS



DANGER

This heater must be earthed



DANGER

Isolate the mains electrical supply to the heater before starting any work and observe all relevant safety precautions


External wiring to the heater must be installed in accordance with current Regulations for the wiring of buildings and to any Local Regulations that may apply.

This heater is designed to operate from a 230V, single phase supply fused at 5 amps. Mains input cable should be at least 0.75mm², 3 core cable.

The method of connection to the mains electricity supply should facilitate complete electrical isolation of the heater. A fused double pole switch or fused spur box serving only the heater should be used. The point of connection and isolation to the mains electricity supply should be readily accessible and adjacent to the heater, and should be connected to the mains supply as detailed above.

4.10.1 ACCESS TO THE TERMINAL CONNECTIONS

Open the heater front door panel to reveal the electrical connections inside (see illustration below).



4.10.2 VOLT FREE CONNECTIONS

This heater has volt free connections, which can be used for a Building Management System or a remote indicator panel. These volt free connections are pre-configured to perform the following functions:

Volt free - Remote enable - Closing this connection will activate the DHW system

Volt Free - Fault Indicator - Immediately after a fault or maintenance warning has been detected by the control system, an internal relay will activate and close the circuit to indicate that a fault has occurred. In order to avoid temporary or short acting faults, a 1 minute delay before the fault is reported by the heater is factory set. This can be changed via parameter 6612, accessible using the GUI screen.

Volt Free - Flame Indicator - When any of the heat engines are in operation, an internal relay will activate and close the circuit to indicate that at least one heat engine is in operation.

4.10.3 COMMUNICATION CONNECTIONS

This heater has communication connections, which can be used for a Building Management System, web server or expansion of inputs/outputs.

Modbus - Is a BMS language protocol which BMS systems can interface with, either directly or through a gateway. Parameter values can be read and written directly to the Master controller

MODBUS SETTINGS:

Menu	Parameter	Settings
Modbus	6651 Slave address	If connecting more than one device to the Modbus network, each appliance must have its own unique slave address.
	6652 Baud rate	All devices in the Modbus network must have the same rate of transmission. The higher the transmission rate the shorter the lines between the devices has to be (doubling the baud rate halves the cable lengths). Recommended baud rate with a cable of less than 500m length "19,200"
	6653 Parity	All devices in the Modbus network must have the same parity. Recommended setting "Even"
	6654 Stop bit	All devices in the Modbus network must have the same number of stop bits (1 or 2). If 2 stop bits are set, then parity must be set to none. Recommended setting is "1"

Comments on Date and time values

Year (8 bit value)	2000 - 2099 = 100...199
Month	1 = January...12 = December
Time program	Time value is in periods of 10 minutes. Example: Switch on time of 06:10 = H-Byte value: 37 Switch off time of 22:00 = L-Byte value: 132

BSB (Boiler System Bus) - Is the communication system of the water heater, which is used to send and receive information from the other controllers (if fitted) and can be used by the optional OZW672 Web Server, to provide access to the heater via the Internet or mobile phone app. Please contact Andrews Water Heaters for further advice.

5.0 COMMISSIONING GENERAL



After installation of pipe work and fittings the water systems can then be filled and evacuated of all air before commencing commissioning. This is best done with the door and inner cover removed (see 4.2 for details)


5.1 FILLING AND REMOVAL OF AIR

5.1.1 DHW TANK AND SYSTEM


In order to ensure safe removal of air from the hot water system, please perform the following:

1. Check that the tank drain shut off valve is closed.

Tank drain shutoff valve



2. If the heater is connected to a hot water recirculation system, open the isolation valve immediately before the connection point to the tank.
3. Turn on all hot water draw off taps.
4. Turn on the cold water supply and fill the DHW tank.
5. Close each hot water draw off tap when water is discharged.
6. After initial filling, open each hot water draw off tap in succession and check that all the air is vented from the system.
7. Check for leaks inside and outside of the heater.
8. Turn on power to heater and operate the Q1 circulation pump by disconnecting the wiring from the front flow sensor (B2) of each heat exchanger. This will automatically operate the pump.



B2 Sensor

9. Continue to operate the pump(s) until the sound of air in the system has diminished.
10. Replace the flow heat exchanger wiring and press the reset for 1s when bleeding is complete.



If the pump does not appear to be rotating, place a cross head screw driver into the hole at the centre of the pump head. Push screwdriver inwards and turn to free the pump.

Free pump here



CAUTION

It is ESSENTIAL that all air is removed from the heater before proceeding with commissioning the heat engines, otherwise permanent damage may occur to the heat exchangers and this damage is not covered by warranty.

5.1.2 FILLING THE CONDENSATE TRAPS

Before operating the burners it is first necessary to ensure that both condensation traps are filled with water. This is best done before the final connection is made to the condensate drain. The following actions are suggested:

1. Rotate the elbow of the condensate trap so that it is facing upward (see photo below).



2. If the condensate pipe is already installed, disconnect the elbow and move pipe away from condensate trap (see photo below).



3. Pour approximately 500ml of water into the trap and replace / reposition pipes.
4. Proceed with the commissioning of the heat engines

5.2 COMMISSIONING THE HEAT ENGINES


5.2.1 IMPORTANT NOTES



CAUTION

The gas mixture and burner off-set gas rate (minimum load rate) is preset by the manufacturer. Please **DO NOT** attempt to change the settings of the off-set governor behind the sealed cover.


Off-set governor cover
DO NOT REMOVE
DO NOT ADJUST



CAUTION

Before starting commissioning of the heat engines, it is important to check that the internal flue pipes have not moved out of place during transportation. Pay special attention to the connection into the top of each heat exchanger. Ensure that the flue pipe is straight and fully inserted into the heat exchanger (see illustration below).

Check flue part is fully inserted
into heat exchanger




The heat engines on this heater have been tested and set by the manufacturer, but this will need to be checked again when the heater has been fully installed into its operating environment. The commissioning process involves the operation of the individual heat engine(s) at the maximum possible heat load.

5.2.2 TOP HEAT ENGINE COMMISSIONING

Ensure that all the numbered points included in section 5.1 “Commissioning General” have been completed successfully before proceeding with the following:


NOTE: A flue sample point is provided in the flue section immediately above the heat exchanger. To use this sample point, carefully remove the rubber bung

Remove rubber bung
to access sample point




- Turn on power supply.
- Access the flue sample test point (see above)
- Insert a calibrated combustion analyser (approximately 65mm) inside the flue sample test point
- Turn on gas supply
- Ensure that the heater is set to “Standby” or “O” on the front switch.
- The heater GUI display to be used to operate the top heat engine unit, when commissioning (see next page for details)

- Use the control thumb wheel to select “Setup” page and press the thumb wheel to select “Special operations” (see below)





- Use the thumb wheel to select the “Chimney sweep” function and use the thumb wheel to activate this function. Select and activate “Full load” for the burner output (see below)



- If this is the first time that the heat engine has been operated, allow for several ignition attempts before ignition is achieved whilst the gas pipework is being purged of air. It may be necessary to press the reset button to start the ignition attempts again.
- Once ignition is successful, allow at least three minutes for the heat engine to warm up fully before checking the combustion.
- Ensure the Boiler temperature remains below 70°C during the commissioning process (see above illustration), if necessary open water outlets to introduce cold water into the tank keeping the boiler temperature down.
- With the heater door open, the CO₂ combustion figure for G20 will be as follows:

Models	CO ₂	Maximum CO expected	Throttle screw depth (mm)
MAXXflo EVO 150	8.9% (+/- 0.2%)	150	10.8 (+/- 1.0mm)

- If adjustment is required, remove the dust cover of gas valve throttle adjustment screw and insert a 4mm allen key or medium flat blade screw driver to adjust (see illustration on next page).



Throttle screw adjuster


MAKE ADJUSTMENTS IN 1/8 TURN STAGES AND WAIT ONE MINUTE BETWEEN EACH ADJUSTMENT



CAUTION

If you are experiencing CO readings that exceed 200 ppm after 20 minutes of burner operation, please first check that your gas analyser is functioning correctly and then contact Andrews Water Heaters on the customer support number given on the rear cover of this manual, for advice.

- When the adjustments are complete, turn OFF the chimney sweep function and wait until the heat generator stops before continuing (see Figure below)



- Remove the gas analyser and replace the rubber bung in the flue sample point
- Replace the throttle screw cover


5.2.3 BOTTOM HEAT ENGINE COMMISSIONING



If the Commissioning Controller (available from Andrews Water Heaters, part code 7729664) is used, the commissioning procedure for the top heat engine (5.2.2) should be followed, to commission the bottom heat engine.

The commissioning controller (if available) is connected to the bottom heat engine controller via the connection port located on the electrical enclosure just above the spark generator (see illustration)

Connection port



If the Commissioning controller is not used the following commissioning procedure must be followed:

- Set the time and date Using the GUI screen




Refer to section 5.1 in the “*CONTROLS OPERATING INSTRUCTIONS MANUAL*”

- Set the DHW heating times for daytime use using the GUI screen




Refer to section 3.3 in the “*CONTROLS OPERATING INSTRUCTIONS MANUAL*”

- Start with the heater set to “Standby” or “O” on the front operation switch.
- Access the flue sample test point (see 5.2.2 for details) by removing the rubber bung
- Insert a calibrated combustion analyser (approximately 65mm) inside the flue sample test point
- Carefully disconnect the PWM connector of the fan from the top heat engine. Push the clip at the end of the connector inwards towards the body of the connector then pull the connector from the fan. Be careful not to pull on the wires.




Ventilator PWM connector

- The top heat engine will now go into fault when called upon to operate, but this can be ignored during this stage of the commissioning process.
- Turn the operation switch to ON or “I”, then rotate the thumb wheel of the GUI and select the DHW tab. Click the thumbwheel in to select this tab. Use the thumbwheel to select and set Temporary “Recharging” Set the Nominal setpoint to 70°C (see illustration below).



- Ensure that the DHW temp 1 is below 40°C at all times during the commissioning . Draw off water to maintain the tank temperature below this value. The temperature can be checked on the home page of the heater display at any time.



- Ensure that the DHW temp 1 is below 40°C at all times during the commissioning . Draw off water to maintain the tank temperature below this value. The temperature can be checked on the home page of the appliance display at any time.



- Once ignition is successful, allow at least three minutes for the heat engine to warm up fully before checking the combustion.
- Ensure the DHW tank temperature remains below 40°C and with the heater door open, the CO₂ combustion figure for G20 will be as follows:

Models	CO ₂	Maximum CO expected	Throttle screw depth (mm)
MAXXflo EVO 150	8.9% (+/- 0.2%)	150	10.8 (+/- 1.0mm)

- If adjustment is required, remove dust cover of gas valve throttle adjustment screw and insert a 4mm allen key or medium flat blade screw driver to adjust.



Throttle screw adjuster

MAKE ADJUSTMENTS IN 1/8 TURN STAGES AND WAIT ONE MINUTE BETWEEN EACH ADJUSTMENT



CAUTION

If you are experiencing CO readings that exceed 200ppm after 20 minutes of burner operation, please first check that your gas analyser is functioning correctly and then contact Andrews Water Heaters on the customer support number given on the rear cover of this manual, for advice.

- When adjustments are complete, turn the operation switch to STANDBY then ON then STANDBY then ON then STANDBY. This will cancel the temporary recharging function. Wait for the heater to stop before proceeding
- Remove the gas analyser and replace the rubber bung in the flue sample point
- Replace the throttle screw cover

5.2.4 HEAT ENGINE COMMISSIONING COMPLETION

- Refit fan PWM connector onto the top heat exchanger, then press the RESET toggle switch for 1 second to clear the control lockout.
- Once the lockout has been cleared from the display (bell symbol is not being displayed) close the door of the heater and secure it with the two door clips.
- Turn the operation switch to ON or "I" and wait for both heat engines to ignite and operate at maximum output.
- Keep the DHW tank temperature below 40°C (by opening water outlets). Check the total gas consumption figure using the following table:

		G20 GAS (38.8 MJ/m ³)		
		<i>Metric meter</i>		<i>Imperial meter</i>
Model	gross kW input	<i>Time taken to consume 0.1m³ of gas</i>	<i>Time taken to consume 0.5m³ of gas</i>	<i>Time taken to consume 5ft³ of gas</i>
MAXXflo EVO 150	149.9	25.0s (+/- 1.3s)	2m 5s (+/- 6.3s)	35.4s (+/- 1.8s)

- The gas consumption must be within 5% of the gross kW input value of the data plate
- Turn off all taps and water draw offs.
- Change the DHW Set-point to back to 60°C to 65°C as required by the user
- Heat engine commissioning is complete

5.3 CONVERSION FROM SECOND FAMILY (NATURAL GAS - G20) TO THIRD FAMILY OF GASES (PROPANE - G31)

This water heater is supplied from the factory already set up for G20 Natural Gas, but each heater can be converted on site to operate on Liquefied Propane Gas (G31).




CAUTION

This conversion **MUST** be carried out by a competent qualified person using **ONLY** the parts provided by the manufacturer.


Before work commences turn off the Mains Electricity and Gas Supply to the heater. The conversion can then be achieved by following these instructions, and must be carried out to all heat exchangers.

- Remove the throttle adjustment screw cover
- Compress the spring clip holding the black air intake hose onto the venturi and remove the hose



Remove 5 x Venturi screws

- Undo and remove all 5 screws securing the venturi to the gas valve and fan
- Remove the venturi completely. If possible, do not disturb the cork gasket if it is stuck to one of the two metal surfaces (this will be helpful during re-assembly)
- Check the size of the LPG orifice is correct (refer to table overleaf) and fit the orifice into the rubber seal that is located in the outlet of the gas valve (see illustrations below)




- Before re-assembly examine the condition of the cork gasket and replace if it is damaged.
- Position the into place between the fan and gas valve. If the cork gasket is free moving, place a screw through the venturi to hold it in place when fitting to the fan (see illustration below)



- Secure the venturi onto the fan using 2 screws
- Secure the venturi onto the gas valve with the remaining 3 screws. Ensure the rubber seal and orifice remains in place inside the gas valve outlet.
- Replace the air intake hose onto the venturi. Compress the spring clip when fitting in place

Model	MAXXflo EVO 150
LPG Orifice size	6.0 mm
Initial Adjustment G20 to G31	0.5 turns anti-clockwise
CO ₂ Combustion Figure - LPG (G31)	9.8% +/- 0.2%

- Using a 4mm allen key or large flatblade screwdriver, make an initial adjustment to the throttle adjustment screw according to the table above.





- Follow the commissioning procedure in section 5.2 from page 35 with the exception that the CO₂ combustion figure should now be as listed in the table above for LPG (G31)



It should not be necessary to turn the throttle screw more than two turns away from the initial adjustment setting to achieve ignition. If this is the case, ensure that the components are refitted correctly and also be aware that the gas carrying pipes may need purging before gas is available for ignition at the burner.

- Allow one minute between adjustments, and do not move the adjuster more than 1/4 turn at any one time
- Replace the cover over the throttle adjustment screw, when adjustment is complete
- Repeat process above for the second heat engine
- Affix the new LPG serial number data label supplied with the heater over the top of the existing natural gas data plate

Fix new data plate
over original



- Fit LPG warning label to heater cover.

5.4 FROST PROTECTION & LEGIONELLA

5.4.1 FROST PROTECTION

The Heater is fitted with automatic Frost Protection. Provided there is mains power, gas connected and the heater is not in a lockout condition, if the temperature registered by the DHW tank temperature sensor falls below 5°C the heat engine will ignite to bring DHW tank temperature up to 6°C before turning off again.

5.4.2 ANTI-LEGIONELLA GENERAL

Legionella bacteria is commonly found in water. The bacteria multiply where temperatures are between 20 - 45°C and nutrients are available. The bacteria are dormant below 20°C and do not survive above 60°C.

Legionnaires' disease is a potentially fatal type of pneumonia, contracted by inhaling airborne water droplets containing viable Legionella bacteria. Anyone can develop Legionnaires' disease, but the elderly, smokers, alcoholics and those with cancer, diabetes or chronic respiratory or kidney disease are at more risk.

The Health and Safety Executive in the UK Advises conducting a complete risk assessment of the hot and cold water systems and ensure adequate measures are in place to control the risks. Recognised measures include but not limited to the following:


- Cold water should be stored and distributed below 20°C
- Hot water cylinders should store water at 60°C or higher.
- Hot water should be distributed at 50°C or higher (any thermostatic mixer valves need to be fitted as close as possible to outlets)
- Use a DHW return pump to circulate water around the system for at least 10 minutes every hour, even when hot water is not required
- Regular temperature checks of hot water tanks (at least every month)
- Regular temperature checks of cold water tanks (if used, at least every 6 months)
- Regular temperature checks of outlets closest and furthest from the hot water tank
- To avoid stagnation, introduce fresh water by ensuring that all outlets are used at least once per week. This draw off must be equal to at least the total quantity of water in the complete system (this includes all stored water in any appliance)
- Clean and de-scale shower heads every 3 months
- Inspect the DHW tank for signs of debris during the annual service. Clean as necessary.
- Design water systems to minimise Legionella growth, by:
 - Keeping pipe work as short as possible
 - Avoid dead legs/dead ends in pipe work
 - Keep water turning over regularly. Fit an anti-legionella valve on the expansion vessel to maintain circulation around the vessel
 - Insulating circulation pipes and any cold water tanks

Other methods to control legionella include copper and silver ionisation and biocide treatments. Consult a water treatment expert for advice on these measures.

This heater has been designed to minimise the formation of Legionella bacteria. The pumped tank charging process ensures that the water at the bottom of the tank reaches the same temperature as in the rest of the tank and all of the water is circulated, with no stagnation possible. A hatch in the main tank can be used for inspection and cleaning. Only metals listed in 4MSI are used in this heater, and the heater has a WRAS UK approval pending.

5.4.3 ANTI-LEGIONELLA SETTINGS

When activated via the heater controls, the anti-legionella function will be satisfied when the DHW tank temperature sensor (B3) has detected that the anti-legionella setpoint has been reached for the length of time set (1646 Legionella function duration). However, when the return sensor (B39) has been installed the temperature requirement to satisfy the anti-legionella function moves from the DHW tank sensor (B3) to the return sensor (B39) mounted on the return pipe before its return to the DHW tank (see illustration on next page).



Menu for Anti-legionella function

Line no	Description	Factory default	Notes
1640	Legionella Function	Off	Choose to have the legionella function activated on a fixed weekday (parameter 1642), every (parameter 1641) number of days or switch the function off.
1641	Legionella function periodically	7 days	No of days before the legionella function will activate
1642	Legionella function weekday	Sunday	Fixed day the legionella function will activate
1644	Legionella function time	01:00	Time the legionella function will start
1645	Legionella function setpoint	70°C	The setpoint to be achieved for the legionella function
1646	Legionella function duration	10 mins	The length of time the DHW tank sensors and B39 circulation return sensor (if fitted) should achieve the setpoint, before the function is completed. If the legionella function cannot be performed successfully within a 48 hour period, an error message will be displayed.
1647	Legionella function circulation pump	On	Choose whether the circulation pump Q4 is on or off when the legionella function is active



In a return system that has a heat loss of more than 3°C, the temperature reached at the B39 sensor may never be enough to confirm that the anti-legionella setpoint has been achieved.

For example: If the legionella requirement was for a 70°C setpoint for 1 minute and the heat losses on the return system were 5°C, The temperature leaving the tank would be at a maximum of 73°C (anti-legionella setpoint + maximum boost) and this would return to the tank at 68°C. The anti-legionella function would never be satisfied in this scenario and the controls would attempt to achieve the anti-legionella setpoint for a total of 48 hours before the controls finally give up and an error message results.



Alternative solution when return pipe system losses are high and the return sensor is installed
If the return sensor functionality is to be retained, an alternative method to achieve a regular anti-legionella function would be to set the following:

- Set “1612 Reduced setpoint” as the normal DHW tank temperature (e.g. 60°C)
- Set “1610 Nominal setpoint” as the temperature required for an anti-legionella cycle (e.g. 70°C)
- Set “5070 Automatic push” to OFF
- Use time program 4 to set the length of time and the day that you want to run your anti-legionella cycle (every day is recommended) – For guidance on the length of time required please refer to the table below:-

Temperature	Time required at setpoint
70°C	1 MINUTE
66°C	2 MINUTES
60°C	32 MINUTES
55°C	6 HOURS

The figures given in the table above are for guidance only. The advice given in Approval Code of Practice (ACOP) L8, “Legionnaires’ disease: The control of legionella in water systems”, and HSG274 Legionnaires’ Disease Technical Guidance, should be followed.”

5.5 FINAL CHECKS & USER HANDOVER

5.5.1 SETTING THE TIME CLOCK AND DHW TIME PROGRAM



NB. The DHW time clock is factory programmed to optimise this heaters efficiency at the declared load profile under Eco-design Regulations.




*It is essential that the time / date is set correctly and the DHW operation times have been programmed according to the requirements of the end user. Refer to the instruction sheet “**QUICK START GUIDE**” or section 2.2 onwards of the “**CONTROLS OPERATING INSTRUCTIONS MANUAL**” for guidance on how to setup the controls.*

5.5.2 CHECKING THE DHW TANK SENSOR POSITION

For optimum control of DHW tank temperature, ensure that the tank sensor is touching the end of the sensor well.

The sensor and sensor well can be located behind an access panel (A) at low level on the left hand side of the heater. Remove 2x fixings that secure the access panel to the side panel. Pull the sensor cable outwards a little above the ‘P’ clip (B) position and feel if the cable springs back under cable tension and is pushed all the way in. You should be able to feel the sensor bottom out against the end of the sensor well which is approx. 150mm deep. Arrange the cable as below in the photo which maintains the cable under tension and also prevents the sensor from being pulled out of the well.



5.5.3 CLEANING THE HEATER

The casing is finished with a polyester coating and will mark if abrasive cleaners are used. It should be cleaned using standard non abrasive cleaning products. A soft cloth used with soap and warm water should be sufficient to clean the casing.

5.5.4 USER HANDOVER

When commissioning is satisfactorily completed the user must be instructed on the safe use and operation of the heater and in particular detail:

- As a bare minimum go progress through the “Quick start guide” with the user, to cover the basic operation of the heater
- Hand over this manual and any other literature supplied.
- Explain the importance of air vents and the flue outlet system, and that they should not be altered or interfered with in any way.
- Explain that the DHW tank temperature should not be set below 60°C for any length of time as this can allow the growth of legionella bacteria. Discuss what methods are in place or setting options to limit the formation of legionella bacteria (see previous page)
- Remind the user that in order to comply to the regulations in force, the heater has to be serviced regularly (at least once every 12 months) and only an engineer who is trained and competent should carry out any work on the heater (i.e. Gas Safe registered engineer).
- Explain that between 10:00 and 10:30 every Friday all pumps being controlled by the heater will be activated in turn for 30 seconds each. This will occur even if the heater is in standby mode. This function is automatic and is designed to help prevent pumps from sticking if the heater has not been in operation for some time.

5.6 FAULT FINDING

5.6.1 OPERATION SEQUENCE

To operate this heater you must have sufficient gas volume and be of the correct gas type. Electricity supply, 220-240v 50Hz and a valid demand from the DHW system.


ALL MODELS

1. The circulation pump is turned on.
2. The gas control starts the ignition sequence following a demand for DHW.
3. The fan operates on the heat engine as a pre-purge of the heat engine airways.
4. After 15 seconds of fan operation, a spark is created at the electrode and the gas valve is opened.
5. The ignition spark and gas valve opening will last for a maximum of 10 seconds.
6. A 10 second period of flame stabilisation will occur immediately after a successful ignition.
7. The controls will check that a flame is present. If no flame is detected, stages 1 - 6 will be repeated 4 further times (within 24 hours) before a permanent lockout of that heat engine occurs.
8. On successful confirmation of a flame, the fan speed is varied by the controls to suit the demand conditions.
9. Both heat engines together, will continue to operate until DHW demand has been met, the control timer has turned off the demand or the controls detect a fault condition.




NB: If one heat engine is in a lockout condition, this should not affect the other heat engine's ability to function and the heater should continue to operate as normal, using the other heat engine.

5.6.2 FAULTS AND LOCKOUTS


If a heat engine is unable to ignite or detects a safety condition, the control of that heat engine will lockout and will be prevented from firing again, without manual intervention. The display will show the  symbol along the top bar of the GUI display to indicate that there is a fault.




Refer to section 6.6 at the end of this manual for a full list of fault codes

The fault will have to be cleared before that heat engine will function again. Selecting from the info pages menu will provide the fault detail (see section 6.6 at the end of this manual for the possible fault codes). Press the RESET button on the front of the heater and provided the condition has been corrected the heat engine will run through the ignition sequence again and the  symbol will disappear from the display after a short delay.

5.6.2.1 FAULT DISPLAY EXAMPLES

The display will show a  if the heater has recorded a fault. More information can be obtained by selecting the info pages menu. See example screen:



CAUTION

A Lockout condition should not be repeatedly reset. If the condition persists then a qualified repair engineer should be called.

6.0 MAINTENANCE



DANGER

In all cases, before work commences turn off the Mains Electricity and Gas Supply to the heater

6.1 ROUTINE INSPECTION INTERVALS AND REQUIREMENTS



To ensure continued efficient operation of the heater it is recommended that it is checked and serviced at regular intervals. The frequency of servicing will depend upon the particular installation and usage but in every case a maximum of twelve months should be allowed between service inspections.



DANGER

It is a legal requirement that any service work should be carried out by a suitably qualified and Gas Safe registered personnel.

6.1.1 RECOMMENDED MINIMUM SERVICING REQUIREMENTS (ANNUALLY OR EVERY 4,000 HOURS)

Does not exclude annual gas safety checks required under Gas Safety (Installation and Use) Regulations 1998.

1. Inspect and clean the following, by removing the burner:
 - Burner tube
 - Vapour seal
 - Rope Gasket
 - Combustion chamber
 - Spark electrode
 - Ionisation electrode
2. Check condition of condensate pipework and empty and clean condensate trap
3. Check ignition performance
4. Inspect internal air and flue system
5. Inspect cover seal for damage or leakage
6. Perform flue gas analysis and set CO₂ if necessary
7. Inspect and flush DHW storage tank (especially in hard water areas)

Replace any worn or defective components as necessary

Follow the procedures given in section 6.2 for parts removal in addition to notes on the following pages:

6.1.1.1 INSPECT AND CLEAN BURNER ASSEMBLY




To view the burner and the inside of the heat exchanger it is recommended that you remove the front of the heat exchanger complete with the fan, venturi and gas valve.

The following steps need to be completed before the combustion chamber and burner can be inspected:-


- Isolate heater from the electrical supply.
- Open the outer heater cover door by removing the screws on the left hand side and opening the door of the heater.
- Disconnect the electrical connections to the fan

Disconnect power supply




Disconnect PWM control

- Disconnect the venturi from the fan, by removing the two cap head screws. Remember to retain the cork gasket for re-assembly



- Disconnect the spark and Ionisation leads
- Undo the six burner door nuts


Disconnect



Disconnect


- Pull the whole burner assembly outwards and left away from the gas valve

6.1.1.1 INSPECT AND CLEAN BURNER ASSEMBLY (CONT)



Once assembly is free from the heat exchanger, carry out the following inspection:

- Inspect the black silicone and rope gaskets on the inside of the heat exchanger door. Replace seals if there are any signs of damage and in any case replacement of the silicone gasket every two years is recommended.
- Inspect the burner tube for signs of damage. Replace if any damage or burnt areas are found.



- Inspect the inside of the heat exchanger for signs of carbon build up or blockages between the tubes.



- The heat exchanger can be cleaned using a nylon (nonmetallic) brush and vacuum cleaner, to remove loose deposits.


- White vinegar can be used to remove stubborn deposits, by spraying the vinegar onto the coils and then waiting five minutes before scrubbing with a nylon brush and finally rinsing away all deposits with clean water, until the condense pipe runs clear.



- At the end of the cleaning process unscrew the condense trap bowl, clean out and refit.




- Inspect the Ionisation and spark electrode assemblies for damage and wear



- Reassembly is the reverse

i When refitting the venturi onto the fan inlet ensure that the cork gasket is in the correct position by using one of the screws to hold the gasket in place



6.1.1.2 SPARK ELECTRODE AND IONISATION ELECTRODE

In order to maintain optimum reliability, it is recommended that both sets of electrodes are replaced every two years regardless of their condition. Both of these electrodes are best inspected when they are still in place and the entire heat exchanger door has been removed (see 6.1.1.1), but can also be inspected by carrying out the following :



- Turn off the heater and pull off the electrode lead(s).
- Unscrew the two screws retaining the spark electrode in position and carefully withdraw. Inspect for damage and correct spark gap (see illustration below).



- Undo the two screws retaining the flame sensing electrode.
- Withdraw and inspect for wear or damage.
- Replace electrode(s) if older than 24 months or if worn or damaged.
- Assembly is the reverse, ensure the gasket is undamaged and correctly placed.

6.1.1.3. CASE AIR & FLUE OUTLET SEALS

- Push on the flue sections to ensure firm connection between the joints.
- A visual inspection should establish there are no leaks around any of the seals, including the flexible air duct to the venturi. Replace if there is any doubt as to the integrity of the seals.




6.1.1.4. CONDENSATE PIPEWORK AND CONDENSATE TRAP

Inspect all joints in the internal condensate pipework (A) for leaks.

The internal pipes (A) should be clear, flexible and no signs of any cracking should be visible. Investigate closer any white coloured areas that may appear on the internal condensate pipe work. Check its connection to the heat exchanger and pipework for leaks.

Inspect all joints in the external condensate pipework (B) for leaks.




The lower bowl of each condensate trap (C) should be unscrewed, examined and cleaned (see illustration below).



6.1.1.5. GAS RATE & COMBUSTION

The gas rate and combustion flue analysis must be carried out when the heater is operating at maximum loading. See Section 5.2 for full details on how to check and adjust the CO₂

To check, re-establish gas and electricity supply and then operate each heat engine for at least 5 minutes. If adjustment is required remove the cover over the throttle screw and turn anti-clockwise to increase CO₂ or clockwise to decrease.



MAKE ADJUSTMENTS IN 1/4 TURN STAGES AND WAIT ONE MINUTE BETWEEN EACH ADJUSTMENT


6.1.1.6 INSPECT AND FLUSH DHW STORAGE TANK

The storage tank should be inspected annually and cleaned if required. To gain access for inspection please carry out the following procedure:

- Turn off the electrical supply to the appliance
- Shut of the cold water supply to the tank
- Open a hot water outlet until water flow stops
- Shut off hot water outlet and return feed to the tank.
- Drain off approximately 5 - 10 litres of water from the tank drain point (see illustration below).



- Remove the insulation material on the top of the tank to reveal the tanks connections.
- If necessary, disconnect any pipework connections to allow removal of the Tank Inspection Hatch.



- Loosen nut on Tank Inspection Hatch and unscrew nut to near the end of the thread, but do not remove.
- Wrap a length of wire around the threaded shaft underneath the clamp and hold the wire to prevent the hatch falling into the tank, when the nut is removed
- Tap the hatch, so that the hatch drops downwards and is held in place by the nut.
- Remove the nut and clamp and while holding the threaded shaft allow the hatch to drop down and then angle the hatch and remove it through the opening.

With the use of a torch it should be possible to see to the very bottom of the inside of the tank. If the tank is clear of deposits then no further action is necessary and the hatch can be replaced as a reverse of the above procedure. Take care not to drop the hatch into the tank when replacing it.

If the tank requires flushing, allow all the water to flow from the tank by opening the drainage tap fully . A hose pipe connected to the cold water supply, can be inserted into the hatch opening to wash away any remaining deposits out of the tank drainage point. In areas with hard water, it maybe necessary to flush out the tank more frequently.

To refill the tank after inspection or flushing, perform the following procedure:

- Close the tank drain point
- Secure the inspection hatch
- Turn on the cold water supply to the tank and open the hot water return pipework
- Open hot water outlets in turn until all air is expelled
- Turn on the power to the heater and activate a hot water demand.

6.2 REMOVING AND CHANGING COMPONENTS



DANGER

NONE OF THE CONTROLS ARE REPAIRABLE . IF THEY ARE NOT FUNCTIONING THEY MUST BE REPLACED In all cases, before work commences turn off the mains electricity and gas supply.

The following items do not require isolating water before removal:


1. DHW tank temperature sensor
2. Flue temperature sensor
3. Common flow temperature sensor
4. GUI display
5. Master & Slave controller PCB
6. Spark generator
7. Combustion fan
8. Gas valve
9. Spark & Ionisation electrodes
10. Back flow prevention air intake valve
11. Overheat thermostat

The following items require isolation of water before removal and bleeding air afterwards:


12. Heat exchanger
13. Internal circulation pump
14. Water pressure sensor

6.2.1 DHW TANK TEMPERATURE SENSOR (B3)


- Remove tank sensor access panel located at low level on LH side of heater (refer to section 5.5.2).
- Gently remove and pull the cable sensor out of the sensor well whilst feeding it down through the 'P' clip so that it can hang free. (note: There is no need to loosen the screw holding the 'P' clip)



- Undo the bulkhead seal located at high level on LH side of bulkhead (removal of PCB cover panel is required). Gently pull the sensor up and through the bulkhead seal.



- Unplug connector from loom.




- Remove sensor.
- Replacement is the reverse.

6.2.2 FLUE TEMPERATURE SENSOR (B8)

This is located at the Flue outlet of the heat exchanger.

- Unplug the sensor from the loom (squeeze the catch to release).




- Remove sensor by unscrewing anti-clockwise
- Replacement is the reverse.

6.2.3 COMMON FLOW TEMPERATURE SENSOR (B10)

This is located on the top left hand side of the case, to the left of the top control PCB

- Unplug the sensor from the loom (Squeeze the catch to release).



6.2.4 GUI DISPLAY

This is located in the centre of the heater inside the front cover.



- Switch off electrical supply to heater
- Remove the 4 fixing screws located at the rear of the screen.



- Push off the wiring connector from the rear of the GUI
- Replacement is the reverse.

6.2.5 LMS14 PCB MASTER & SLAVE REPLACEMENT




ATTENTION

Electrostatic sensitive PCB - Handle PCB by edges only and if available wear an earth wristband

This is located on the bridge. It is important that the correct PCB replacement is used. Check that the model matches the replacement PCB

- Carefully push off all the connectors on the PCB (be careful not to pull on the wires).



- Release in turn, all seven PCB support posts by squeezing together the end of the support and withdrawing the board from each support, one at a time.
- Replacement is the reverse.


6.2.6 SPARK GENERATOR

- Remove the power connections
- Remove the ignition cable
- Remove the 2 fixing screws

Power connections:

Pink = 1

White = 2




- Replacement is the reverse


6.2.7 COMBUSTION FAN

The combustion fan is best removed when the whole burner assembly has been detached from the heat exchanger (see 6.1.1.1), but can also be removed individually if these steps are followed:

- Turn OFF the electricity to the heater.
- Carefully remove the two electrical connectors from the fan.
- Remove the two cap screws securing the venturi to the fan.



- Remove the four bolts securing the fan to the air arm.



- Slide fan off venturi and remove
- Inspect both the venturi gasket and air arm gasket and replace if damaged.
- Replacement is the reverse



CAUTION


Please ensure that the cork gasket between the fan and the venturi is correctly placed before fixing the two venturi screws. Place a screw through the venturi to hold the gasket in place when refitting to fan



- Operate the heat engine and check for gas leaks. After five minutes check the rate and combustion is correct to the table on page 11. Adjust using the throttle screw on the gas valve clockwise to decrease CO₂ anti-clockwise to increase CO₂ if required (see 5.0 for details).

6.2.8 GAS VALVE

- Turn off the gas supply at the burner gas cock isolator



- Carefully remove the electrical connectors of the gas valve
- Remove the allen bolts securing the gas pipe to the valve
- Release the gas valve from the venturi by undoing three cap screws

Remove venturi cap screws




- Transfer the rubber gasket to the new gas valve and orifice if fitted .
- Replacement is the reverse.
- Operate the heat engine and check for gas leaks.
- After five minutes check the rate and combustion is correct to the Data table. (page 11). Adjust using the throttle adjustment screw on the gas valve if necessary. Turn clockwise to decrease CO₂, anti-clockwise to increase CO₂ (see 5.0 for details)



NB Valve Coil resistances are 2.8k and 1.6k ohms

6.2.8 ELECTRODE REMOVAL


These are located on the front of the heat exchanger.



- Carefully pull off the electrical connectors.
- Undo the two screws retaining the bracket and withdraw.
- Replacement is the reverse ensuring that the gasket seal is placed correctly and is in good condition.

6.2.10 BACK FLOW PREVENTION VALVE

- Remove the 8 Torx screws holding the cover plate onto the air arm and gently pull cover away from the seal.
- The Back Flow Prevention Valve (BFPV) is located inside the cover itself and can be slid out for inspection.




- Inspect BFPV for damage and operation. Replace if necessary
- Inspect air arm seal for damage. Replace if necessary
- Assembly is the reverse

6.2.11 OVERHEAT THERMOSTAT

- Locate the overheat thermostat behind the GUI bridge (see illustration below)
- Remove the thermostat from the clip by pushing the assembly upwards
- Disconnect the two wires
- Assembly is the reverse

Push thermostat upwards






CAUTION


Changing the following components will require some draining of the water system. After reassembly, it is essential that all the air is removed from the heat exchanger before the heater is operated. Failing to do so may damage the heat exchanger and invalidate the warranty.

6.2.12 HEAT EXCHANGER


- Turn off the water isolators located before and after the heat exchanger (see below):



- Drain water using the drain points to ensure the heat exchanger is as empty as possible.
- Disconnect all electrical connections to the flue, flow and return sensors.
- Disconnect the flue from the top of the heat exchanger by pushing the flue section upwards so that it clears the heat exchanger




- Disconnect the electrical connections to the ionisation probe, ignition probe, fan and gas valve and place wiring to one side.




- Remove the air intake from the venturi by squeezing the spring clip together, and disconnect offset tube

- Remove the 6 heat exchanger door bolts and remove the whole burner assembly and put to one side.



Removed burner assembly

- Unscrew the flow and return pipework from the heat exchanger.
- Unscrew the flow and return sensors from the heat exchanger and retain
- Disconnect the condense drain connection by releasing the jubilee clip and pulling the pipe off



Jubilee clip

Condense hose

- Remove the 6 screws of the heat exchanger retaining clamps and remove the clamps



CAUTION

This item is heavy - Before releasing the brackets ensure support is available

- Carefully lift out the heat exchanger
- Fitting is the reverse



CAUTION


After refitting ensure no air is present in the heat exchanger by running the unit with the gas turned off until the heat exchanger is operating quietly

6.2.13 CIRCULATION PUMP Q1

- Close the shut off valve before and after the pump (see 6.2.12)
- Use the drain points between the shut off valves to remove water from the pump.
- Remove the PWM and power connectors, using a small flat blade screwdriver to lift the white tab before pulling each connector free.
- Carefully undo the unions at the top and bottom of the pump body and remove pump.
- Fit the new pump seals




- Replacement is the reverse
- Refill and bleed air from the pipe work.
- Operate the pump for at least 1 minute by disconnecting the electrical connector from the heat exchanger front flow sensor (B2)




- When all sound of air has stopped, reconnect B2 sensor and press the reset for around one second.

6.2.14 WATER PRESSURE SENSOR

- Close both water shut-off valves and use one of the drain points to drain down water until no further release of water occurs.
- Carefully remove wiring connector from the sensor - using a small screwdriver to gently lift the tabs on each side of the connector in turn, whilst at the same time gently pulling on the connector



- Pull out the metal locking clip, and keep to one side



- Turn and pull out sensor
- Replacement is the reverse

6.3 FLUSHING/DESCALING THE HEAT EXCHANGERS



A flushing kit (P/N 7800417) is available from Andrews Water Heaters. This kit enables easier connection directly onto the heat exchanger and speeds up descaling. Follow the instructions provided in the kit.

CAUTION
Protect electrical components from water contact during the procedure.

CAUTION
It is **ESSENTIAL** that all air is removed from the water before proceeding with operating the heat engines, otherwise permanent damage may occur to the heat exchangers and this damage is not covered by warranty.

Flushing procedure (twin heat exchanger models)
note: see page 1 for single heat exchanger models.


1. Before commencing, isolate the Mains Cold Water supply, the Domestic Hot Water (DHW) FLOW, the Domestic Hot Water SECONDARY RETURN, GAS & POWER to the heater.
2. To gain access to the heat exchangers remove the door and inner cover. (refer to section 4.2 of the installation and maintenance manual).
3. Isolate the top heat exchanger (K) and drain off water using hose drain off points (L).
4. Remove the 1" top heat exchanger Flow and Return pipework, and attach the 2 x Flushing connectors (A), and fibre seals (B) to the Flow and Return connections of the top heat exchanger (M).
5. Attach the flushing device hoses (G) to the 22mm copper tails (A) using suitable fittings (not supplied).
6. Flush and descale the heat exchanger using chemical and flushing device suitable for potable water.
7. When completed, flush with clean water and then remove flushing connectors (A) and retain fibre seals (B).
8. Inspect original fibre seals for damage and replace if necessary with spare fibre seals supplied in flushing kit (B). (The part number to reorder spare fibre seals is: 7720038).
9. Re-attach the Flow and Return pipework to the top heat exchanger (M) with fibre seals placed between the flat faces.
10. Close drain off points (L) and Open isolation valves (K) checking for leaks.
11. Repeat process for the lower heat exchanger by isolating (N) and draining water from lower heat exchanger using hose drain off points (P).
12. Remove the 1" lower heat exchanger Flow and Return pipework, and attach the 2 x Flushing connectors (A) and fibre seals (B) to the Flow and Return connections of the lower heat exchanger (Q).
13. Attach the flushing device hoses (G) to the 22mm copper tails (A) using suitable fittings (not supplied).
14. Flush and descale the heat exchanger using chemical and flushing device suitable for potable water.
15. When completed, flush with clean water and then remove flushing connectors (A) and retain fibre seals (B).
16. Inspect original fibre seals for damage and replace if necessary with spare fibre seals supplied in flushing kit (B). (The part number to reorder spare fibre seals is: 7720038).
17. Re-attach the Flow and Return pipework to the lower heat exchanger (Q) with fibre seals placed between the flat faces.
18. Close drain off points (P) and Open isolation valves (N).
19. Check for leaks and open Mains Cold Water supply, the Domestic Hot Water FLOW and the Domestic Hot Water SECONDARY RETURN connections to the heater.
20. With the GAS supply isolated, and in order to remove air from the pipework, turn on POWER to the heater and operate the Q1 circulation pumps by disconnecting the connectors of the front flow sensors (B2) of both heat exchangers. This will automatically operate both of the pumps (Q1).
21. Continue to operate the pumps until all the air has been removed from the heat exchanger and pipework.
22. Open DHW outlets to remove all air from tank. Close DHW outlets when all air is removed. Vent (E) as necessary.
23. Replace the flow sensor connectors of both heat exchangers (B2) and press the reset for 1 second (J) when bleeding is complete.
24. Check again for leaks before refitting inner cover and door.
25. Open GAS supply and return heater to operation.



CAUTION

Operation of the burner during the de-scaling process is not recommended, as this could result in damage to the heat exchanger.


6.4 COMPONENT ILLUSTRATIONS TANK & SUNDRY SPARES



Item No.	Description	Part Number
100	RETURN SENSOR KIT	7720071
105	TEMP SENSOR DHW TANK B3	7709329
107	28MM OBTUSE COMP. ELBOW	7709372
108	OPTION - CASTOR ASSEMBLY	7709385
109	CONDENSATE TRAP	7617073
110	TEMPERATURE/PRESSURE RELIEF VALVE 10 BAR/95°C	7727952
111b	1" GAS COCK C/W TEST NIPPLE 150KW	7805970
112b	1" GAS UNION M&F 150KW	7805971
113	OPTION - ANTI VAC VALVE C/W HATCH	7818123
114	ACCESS HATCH ASSY INC O-RING	G175
115	300 LITRE TANK WITH SIDE SENSOR WELL	7818124
116	CHECK VALVE ASSEMBLY 1 INCH	7818125
117	1" x 1.25" TUNDISH	5139811

6.4 COMPONENT ILLUSTRATIONS


INNER COVER & DOOR SPARES



Item No.	Description	Part Number
200	DOOR FOR MAXXflo EVO 150KW	7805974
201	DOOR CLOSING LATCH SET	7709375
202	DOOR HINGE SET	7709376
203	DOOR GASKET MAXXflo EVO 300L	7709378
204	INNER COVER MAXXflo EVO 300L	7709380
205	INNER COVER FIXING SCREWS	7709381

6.4 COMPONENT ILLUSTRATIONS (CONTINUED)


GENERAL COMPONENTS




Item No.	Description	Part Number
300	CABLE GLAND	7709386
301	SPARK GENERATOR	7709314
302	LEAD FOR SPARK ELECTRODE	7709313
303	PRESS. SENSOR WATER	7709328
304	22MM RIGID FAN GAS COCK	7709371
306	PUMP FOR MAXXflo EVO	7709310
307	PUMP / NRV GASKET	7720039
308	TEMP. SENSOR CASCADE B10	7709330
309	28MM COMPRESSION TEE	7709368
311	28MM ISOLATION VALVE	7709366
312	DRAIN VALVE 22MM	7727903
313	IONISATION ELECTRODE LEAD	5142139

6.4 COMPONENTS ILLUSTRATIONS (CONTINUED)

DRAIN COMPONENTS




FLUE COMPONENTS



Item No.	Description	Part Number
403	FLUE SYSTEM TWIN H/E MAXXflo EVO	7709361
405	FLUE SEAL SET TWIN H/E MAXXflo EVO	7709363
415	REMOVABLE 200MM AIR DUCT PLATE ASSY	7776499
416	CONDENSATE SYSTEM TWIN H/E	7818126

6.4 COMPONENTS ILLUSTRATIONS (CONTINUED)

HEAT ENGINE SPARES




6.4 COMPONENTS ILLUSTRATIONS (CONTINUED)

HEAT ENGINE SPARES (CONTINUED)


Item No.	Description	Part Number
500	TEMP. SENSOR FLOW RETURN B2/B7	7709317
501	TEMP. SENSOR FLUE B8	7709318
502	H/E SILICONE DOOR SEAL	7709294
503	H/E ROPE DOOR SEAL	7709295
504	H/E BURNER DOOR ASSY	7720060
505	H/E NUT SET FOR BURNER DOOR	7709297
506c	BURNER FOR 75KW HEX	7805976
507	H/E AIR ARM GASKET	7709300
508	H/E CONNECTION GASKET	7720038
509d	HEAT EXCHANGER 75KW	7805977
510	22X1/2" BSPM STRAIGHT CONN	7709369
511	H/E BURNER DOOR INSULATION	7709296
512	IONIS. ELECTRIC INC GASKET+SCREWS	7709311
514	SPARKELECTR. INC GASKET+SCREWS	7709312
515	GAS VALVE	7709308
516c	LPG KIT FOR MAXXflo EVO 150KW	7805978
518	FLUE BACKFLOW PREV. DEVICE ASSY	7709315
519b	AIR HOSE (INC. CLIP) 150KW	7805979
520d	VENTURI 150KW	7805980
521	VENTURI GASKET	7709304
522	FAN GASKET	7709302
523	FASTENER SET FOR FAN-VENTURI	7709303
524	FAN	7709301

6.4 COMPONENTS ILLUSTRATIONS (CONTINUED)

WIRING CENTRE SPARES




SLAVE SPARES



Item No.	Description	Part Number
600	OCI345 COMMUNIC. DEV. C/W CABLE	7709285
601	MODBUS CLIP-IN MODULE KIT	7720069
602	OPTION - CLIP IN EXPANSION MODULE KIT	7720070
603f	CONTROL PCB FOR MAXXflo EVO 150	7805981
604	CONTROL PCB FUSES (2 PACK)	7709324
606	DIN RAIL TERMINAL BLOCK	7709334
607	TEMP LIMIT THERMOSTAT 90°C	7709331
608	ON/OFF SWITCH	7709332
609	RESET SWITCH	7709333
610	GRAPHICAL USER INTERFACE	7709326
611c	SLAVE CONTROL PCB (MAXXflo EVO 150)	7805982
613	OPTION - WEB SERVER	7726955
614	WIRING LOOM UPPER MAXXflo EVO	7818127
615	WIRING LOOM LOWER MAXXflo EVO	7818128

6.4 COMPONENTS ILLUSTRATIONS (CONTINUED)

COPPER PIPEWORK SPARES



Item No.	Description	Part Number
800b	PIPE GAS MANIFOLD 150KW	7805983
802a	PIPE UP. 30&45KW H/E GAS 22MM	7709352
802b	PIPE UP. 60&75KW H/E GAS 22MM	7709353
807a	PIPE LO 30&45KW H/E GAS 22MM	7709354
807b	PIPE LO 60&75KW H/E GAS 22MM	7709355
808	PIPE TWIN LOW H/E CO. RE. AS. 28	7709340
809c	PIPE TWIN 90KW LOW H/E CO.FL.AS 28	7709344
812	PIPE TWIN H/E RE. MA. AS. 28MM	7709336
814	PIPE TANK CONN. FLOW 28	7818129
815	PIPE ALL UP. H/E CO. RE. AS. 22	7818130
816b	PIPE UP. H/E CO. FL. AS. 150KW	7818131
817c	PIPE UPPER H/E FLOW 28 150KW	7805984
818	PIPE TWIN LOW H/E FL.IV.AS 28	7818132
819	PIPE TWIN UP H/E RE. IV. PU. 28	7818133
820	PIPE TWIN LOW H/E IV. PU. RE. AS. 28MM	7818134

6.5 RECOMMENDED SPARES REQUIREMENTS

Emergency parts recommended to be kept on site

The following components are recommended to ensure fast recovery times in the event of a heater component failure. An engineer attending a breakdown on site can immediately use the contents of the 1st aid kit to make a rapid repair. Once a component is used it must be replaced at the earliest possible opportunity to ensure rapid breakdown recovery abilities are retained.

Essential First Aid kit contents to maintain at least one heat engine in operation*

- 1 x Gas valve
- 1 x Fan
- 1 x LMS14 PCB (PCB1)
- 1 x Q1 Pump
- 1 x Spark generator
- 1 x Ionisation electrode + gasket
- 1 x Spark electrode + gasket
- 1 x H3 Pressure sensor
- 1 x 10kΩ B2 Flow or B7 return temperature sensor
- 1 x 10kΩ B3 Tank temp sensor
- 1 x 20kΩ B8 Flue temp sensor

Essential First Aid kit contents (in addition to above) to maintain two heat engines in operation*

- 1 x 10kΩ B10 Cascade sensor (without it, will still operate master heat engine)

**In the unlikely event of multiple component failure (for twin heat engine models), additional components may be required*

6.6 ERROR CODES

Error Code	Error Code Description	Diag. Code	Notes
20	Boiler temperature 1, sensor error	Other	Boiler flow sensor (B2) is outside normal limits
		439	Boiler flow sensor (B2) is short-circuit. Check connection for possible contamination or faulty sensor.
		440	Boiler flow sensor (B2) is open-circuit. Check connection for possible contamination or faulty sensor.
26	Common flow temperature sensor error	Any	Check connections or replace faulty sensor located on common flow pipe work up stand section (B10)
28	Flue gas temperature, sensor error	539	Flue gas sensor (B8) is short-circuit. Check connection for possible contamination or faulty sensor.
		543	Flue gas sensor (B8) is short-circuit. Check connection for possible contamination or faulty sensor.
		540 544	Flue gas sensor (B8) is open-circuit. Check connection for possible contamination or faulty sensor.
40	Return temperature 1, sensor error	Other	Boiler return sensor (B7) is outside normal limits
		441	Boiler return sensor (B7) is short-circuit
		442	Boiler return sensor (B7) is open-circuit
50	DHW temperature 1, sensor error	55	Check connections or replace faulty DHW tank sensor (B3)
81	LPB short-circuit or no power supply	67	LPB Short circuit or no bus power supply. Check external connections onto the LPB terminals are the not shorted and the correct polarity. Inspect connections from the GUI to the Control PCB.
82	LPB address collision	103	LPB address duplicated on another Siemens controlled appliance. Check addresses of all Siemens controlled appliances via parameter 6600
83	BSB short circuit	595	No BSB communication or wires shorted - Check operation of GUI or OZW672 (if fitted)
84	BSB address collision	104	Two appliances connected through BSB (e.g. OZW672) have the same allocation address. Change one of the appliances address via parameter 6600
98	Extension module 1, error	605	Indicates that an expansion module can no longer be "seen" by the controls. To clear this message perform a "Store sensors" (parameter 6200) command, to perform a controls handshake with all connected sensors and ancillaries NB: When applying power to the heater, this fault message may appear briefly, but should self clear within 5 minutes. If message persists perform a "Store sensors" command
99	Extension module 2, error	Any	AGU2.5 configuration error - See also Error 98
100	More than one clock time master	105	Only one device should be set as the time master, check on the GUI (parameter 6640) and any OZW672 connected (in case of connection to an OZW672, this device should be the master)
102	Clock master without power reserve	106	The control PCB battery backup for the time clock has been depleted following the restoration of power to the heater. If this message has not cleared within 10 minutes of power being turned on, turn the power off, wait 10 seconds and turn the power on again. This message does not prevent the operation of the heater in any way.
105	Maintenance message	87	Item requiring attention but not preventing appliance operation (e.g. 12 Month service due). Check details of message on the appliance Front GUI screen.

6.6 ERROR CODES (CONTINUED)

Error Code	Error Code Description	Diag. Code	Notes
110	SLT Lockout	306 431 432 433 434 435 436 756	Electronic temperature limits exceeded. General overheating issue. Check for pump operation, trapped air and heat exchanger blockages. Monitor temperatures of system to establish problem area.
		429 818	Safe reset of the error sub code 433 (see above) has not been met. Allow the boiler to cool further before resetting.
		305 412 550 551 754	Mechanical overheat protection circuit is open circuit (connection X18 on control PCB). Check connector is fully inserted
		426 437 815	Flow temperature heat up gradient exceeded. Check pump operation and presence of trapped air in the heat exchanger. Flow through heat exchanger may be restricted.
		438 817	Maximum Delta T of system exceeded. Check pump operation and presence of trapped air in the heat exchanger. Flow through heat exchanger may be restricted.
		428	Maximum Delta T of system exceeded. Initial operation of the pump before the burner is operated, can cause this error. If accompanied by code 429 within the same minute, this error can be disregarded.
		429	Safe reset of the error sub code 428 /438 (see above) has not been met. Allow the boiler to cool further before resetting.
		427 816	Safe reset criteria has not been met. Allow the boiler to cool further before resetting.
		420 421 819 820	Return temperature greater than flow temperature. Check that the flow and return sensors are operating correctly
		419 430 813 814	Flow temperature limit exceeded. Check for overheating issues and flow sensor (B2) performance.
		809 810 422 423	Flow temperature not plausible - Reading less than 0°C or greater than 124°C . Check flow sensor (B2) and replace if necessary.
		425 812	Return temperature limit exceeded. Check for overheating issues and return sensor (B7) performance.
		424 811	Return temperature not plausible - Reading less than 0°C or greater than 124°C . Check return sensor (B7) and replace if necessary.
111	Shutdown limit thermostat	264	Heat exchanger temperatures have been exceeded. Investigate flow rates, shutoff valves and controls to determine causes of temporary fault code.
125	Maximum boiler temperature exceeded	286 500 740	Temperature supervision lockout. Check pump, shutoff valves, burner and flow rates before resetting
		501	Temperature has not increased at flow sensor after burner start. Check flow sensor is correctly connected
		502	Temperature has not increased at return sensor after burner start. Check return sensor is correctly connected.
126	DHW charging temperature not reached	72	Charging temperature not achieved within parameterised time scale. Check operation and heat up times for heater
127	DHW legionella temperature not reached	73	Check operation of legionella function and DHW system. Legionella setpoint has not been achieved within 48 hours of the legionella function operating. NB: When using a secondary return system and B39 sensor, do not set the legionella function setpoint too high, as the heat losses of the hot water pipework may not permit this setpoint at the return point before the heater.

6.6 ERROR CODES (CONTINUED)

Error Code	Error Code Description	Diag. Code	Notes
128	Loss of flame during operation	244 625	Count of loss-of-flame incidents exceeded (a maximum of 15 loss of flame incidents are permitted in a 24 hour period)
		394 834	Flame lost in operation during safety time, before the start of the modulation phase. Check the burner CO ² is set correctly. Check operation and condition of the ionisation electrode.
		854	Flame lost in operation within the first 7 seconds after safety time. Check the burner CO ² is set correctly. Check operation and condition of the ionisation electrode.
		253	Flame lost in modulation phase
130	Flue gas temperature too high	Any	Check causes of high temperatures before operating Appliance. Inspect inside of heat exchanger for dirt build up. Check CO ₂ levels at min and max output.
133	Safety time exceeded	254 395 755	Records individual ignition failures and the times they have occurred. Check gas supply, spark electrode, spark generator, ionisation probe, burner CO ² setting and flue system
		245 625 757	A total of 5 unsuccessful ignition attempts has occurred within a 24 hour period, resulting in a permanent lockout
142	Device failure (Bus)	Any	Check that the appliance and OZW672 is powered and connected correctly.
151	BMU Internal error	330	Error when closing ignition relay - Check ignition generator and controls connections - Replace control PCB if no fault found
		331	Error when opening ignition relay - Check ignition generator and controls connections - Replace control PCB if no fault found
		332	Error when closing gas valve relay - Check gas valve and controls connections - Replace control PCB if no fault found
		333	Error when opening gas valve relay - Check gas valve and controls connections - Replace control PCB if no fault found
		336 337	Internal safety relay error - Check if polarity of live and neutral has been reversed to the appliance. Replace PCB if fault repeatedly occurs.
152	Parameterization error	Any	Incorrect / conflicting parameters input (last changed parameters need to be investigated).
153	Unit Locked	622	Temperature inside the appliance casing has exceeded 90°C. Check heat engine door seals and door nuts are correctly tightened. Pressing the reset for more than 10 seconds will also produce this lockout.
		848 849	Parameter update finished. Press reset to apply changes.
160	Fan speed threshold not reached	233 749	Fan does not reach required speed setpoint via PWM control- Check wiring and operation of fan. Replace fan if necessary
		377	Fan speed not reached - Home run stage
		378	Fan speed not reached - Standby stage
		379	Fan speed not reached - Ignition stage
		380	Fan speed not reached - Pre purge stage
		381	Fan speed not reached - Post purge stage
162	Air pressure switch	Any	Air pressure switch (APS) has activated or is open circuit. Check flue restriction or incorrect flue installation. Check APS function (Open circuit at 365 Pa). Check the condensate pipe system is free to flow into the trap and beyond.

6.6 ERROR CODES (CONTINUED)

Error Code	Error Code Description	Diag. Code	Notes
171	Fault input 1	Any	User defined OZW672 input D1 has been activated.
172	Fault input 2	Any	User defined OZW672 input D2 has been activated.
183	Unit in parameterisation mode	770	Code will be displayed when a programming stick is used but should clear when programming is complete. Repeat stick operation if fault code persists
		Any	Press reset after any programming has been actioned to remove lockout
217	Sensor error	765 766	Ionisation current fault or short circuit. Check operation of ionisation probe using parameter 8329 (menu - Diagnostics heat generation). Ionisation probe may need replacing. Check electrical supply to the heater and burner - pay special attention to the earth circuit.
218	Pressure supervision	Any	Water pressure inside appliance is low but not yet critical. Appliance will continue to operate but at 80% of maximum output. Full output power will not be available until the water pressure is at or above 0.2 bar.
317	Mains frequency outside permitted range	275 461	The frequency (Hz) of the electrical supply is outside permitted tolerance. Check electrical supply to heater.
322	Water press 3 too high	Any	Water pressure inside the appliance is too high for safe operation. Operation automatically resumes once water pressure is below maximum levels. Check that the appliance flow is not restricted or blocked, or the water isolator valves are shut off.
323	Water press 3 too low	Any	Water pressure inside appliance is too low for safe operation. Operation automatically resumes once water pressure is above 0.1 bar.
324	Input BX, same sensors	110	BX sensor duplicated - Two sensor inputs have been defined twice with the same sensor type (e.g. B3). Review last parameters programmed to remove duplication.
325	Input BX/extension module, same sensors	Any	BX expansion module 1 sensor duplicated - Two sensor inputs have been defined twice with the same sensor type (e.g. B3). Review last parameters programmed for the expansion module to remove duplication.
327	Extension module, same function	Any	AGU2.5 extension module function duplicated - check parameter setup for the AGU2.5 extension module ("Configuration" menu)
335	Sensor input BX21 without function	211	A sensor has been detected connected to BX21 of the AGU2.5 expansion module 1, but not defined. Define the sensor using the parameters or remove the sensor if not required.
		213 215	As above except the undefined sensor is connected to an AGU2.5 expansion module. The AGU2.5 expansion module should be defined as module 1 - Check the dip switches on the front of the device is set correctly
336	Sensor input BX22 without function	Any	See Error 335 for guidance
353	Cascade flow sensor B10 missing	Any	Check connections and configuration of common flow temperature sensor (B10), which is located at the feed into the tank on the front, left, mid section of the appliance

6.6 ERROR CODES (CONTINUED)

Error Code	Error Code Description	Diag. Code	Notes
384	Extraneous light	252 393	Ionisation current detected before whilst in standby mode. Check ionisation current ("Diagnostics producer" parameter 8329). If the current present is greater than 0.61 whilst the burner is in standby, turn off the gas supply to check gas valve is closing completely. If current is still present, remove ionisation probe and use a screwdriver to clear the opening through the burner door before replacing the probe and testing again. <i>Persistent errors may indicate that the burner is only operational for very short periods. Try increasing the switching differential by at least 1°C (parameter 5024) to increase burner run time.</i>
		Other	Ionisation current detected during ignition phase before the gas valve is opened.
385	Mains under voltage	554 555	Mains voltage below 185v - check electrical supply to the appliance.
386	Fan speed tolerance	388	Fan outside allowed speed tolerance during standby phase
		531 389	Fan outside allowed speed tolerance during pre-purge phase
		374 383 384	Fan outside allowed speed tolerance during ignition phase.
		375 386	Fan outside allowed speed tolerance during min modulation phase.
		385	Fan outside allowed speed tolerance during max modulation phase.
		532 534 382 390	Fan outside allowed speed tolerance during post-purge phase
		Other	Check connections and wiring loom of the fan. Replace fan if no fault found. If necessary use parameter 9650 Chimney drying mode to test the function of the fan without having to operate the burner
432	Function earth not connected		No Ignition earth, X1 / X17 not connected or earth fault. Check internal and external earth wiring to the heater
433	Heat exchange temperature	Any	Heat exchanger temperature is too high. Investigate all sources of overheating. When the issue has been resolved examine the heat exchanger for damage before putting back into operation.
NA	DHW Operating mode locked - Cannot operate in DHW mode (No fault displayed)	Any	Remote system enable operating. Check to see if link wire is still in place or controls wired to these terminals are closing this circuit. When the appliance is operating via the volt free enable signal, it is not possible to operate the appliance manually via the GUI if the signal is not enabled (circuit closed).

SENSOR RESISTANCE VALUES

NTC 10K Sensors

(all sensors except for flue sensor)

Temperature (°C)	Resistance (Ohms)	Temperature (°C)	Resistance (Ohms)
0	32,555	55	2,989
5	25,339	60	2,490
10	19,873	65	2,084
15	15,699	70	1,753
20	12,488	75	1,481
25	10,000	80	1,256
30	8,059	85	1,070
35	6,535	90	915
40	5,330	95	786
50	3,605	100	677

NTC 20K Sensors

(flue sensor only)

Temperature (°C)	Resistance (Ohms)	Temperature (°C)	Resistance (Ohms)
0	67,650	90	1,845
10	40,491	100	1,377
20	25,099	110	1,043
25	20,000	120	801
30	16,057	130	624
40	10,569	140	491
50	7,140	150	392
60	4,938	160	315
70	3,489	170	256
80	2,515	180	210

Blank page

Blank page



Sales 0345 070 1055

Technical 0345 070 1057

Web andrewswaterheaters.co.uk



Registered office address: Baxi Heating UK, Brooks House, Coventry Road, Warwick CV34 4LL

April 2022

Andrews. Built to perform.



COMMERCIAL SOLUTIONS FROM **BAXI HEATING**